Register your product and get support at
www.philips.com/welcome



EN **User manual**

32PFL8605
37PFL8605
40PFL8605
46PFL8605
52PFL8605

PHILIPS

2010 © Koninklijke Philips Electronics N.V.
All rights reserved. Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

Philips reserves the right to change products at any time without being obliged to adjust earlier supplies accordingly. The material in the user manual is believed adequate for the intended use of the system. If the product, or its individual modules or procedures, are used for purposes other than those specified herein, confirmation of their validity and suitability must be obtained. Philips warrants that the material itself does not infringe any United States patents. No further warranty is expressed or implied.

Warranty

No components are user-serviceable. Never open or remove covers and never insert objects in the ventilation slots or insert objects not suitable for the specific connectors. Repairs may only be done by Philips Service Centres and official repairshops. Failure to do so shall void any warranty, stated or implied. Any operation expressly prohibited in this manual, any adjustments, or assembly procedures not recommended or authorised in this manual shall void the warranty.

Pixel characteristics

This LCD product has a high number of colour pixels. Although it has effective pixels of 99,999% or more, black dots or bright points of light (red, green or blue) may appear constantly on the screen. This is a structural property of the display (within common industry standards) and is not a malfunction.

Open source software

This television contains open source software. Philips hereby offers to deliver or make available, upon request, for a charge no more than the cost of physically performing source distribution, a complete machinereadable copy of the corresponding source code on a medium customarily used for software interchange. This offer is valid for a period of 3 years after the date of purchase of this product. To obtain the source code, write to
Open Source Team, Philips Electronics
High Tech Campus Bld HTC-44
5600 AE Eindhoven
The Netherlands
E-mail: open.source@philips.com

Compliance with EMF

Koninklijke Philips Electronics N.V. manufactures and sells many products targeted at consumers, which, like any electronic apparatus, in general have the ability to emit and receive electromagnetic signals. One of Philips' leading Business Principles is to take all necessary health and safety measures for our products, to comply with all applicable legal requirements and to stay well within the EMF standards applicable at the time of producing the products. Philips is committed to develop, produce and market products that cause no adverse health effects. Philips confirms that if its products are handled properly for their intended use, they are safe to use according to scientific evidence available today. Philips plays an active role in the development of international EMF and safety standards, enabling Philips to anticipate further developments in standardisation for early integration in its products.

ESD regulation

This apparatus meets performance criteria A for ESD. In case the apparatus does not recover in DLNA mode due to electrostatic discharge, user interference is required.

Mains fuse (UK only)

This TV is fitted with an approved moulded plug. Should it become necessary to replace the mains fuse, this must be replaced with **a fuse of the same value as indicated** on the plug (example 10A).
1. Remove fuse cover and fuse.
2. The replacement fuse must comply with BS 1362 and have the ASTA approval mark. If the fuse is lost, contact your dealer in order to verify the correct type.
3. Refit the fuse cover.
In order to maintain conformity to the EMC directive, the mains plug on this product must not be detached from the mains cord.

Copyrights

VESA, FDMI and the VESA Mounting Compliant logo are trademarks of the Video Electronics Standards Association.
Manufactured under license from Dolby Laboratories. 'Dolby', 'Pro Logic' and the double D symbol, are trademarks of Dolby Laboratories.
Windows Media is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.
DLNA®, the DLNA logo and DNLA Certified™ are trademarks, service marks, or certification marks of the Digital Living Network Alliance.

All other registered and unregistered trademarks are the property of their respective owners.

Europe
EC Declaration of Conformity

English
Hereby, Philips Innovative Applications N.V. declares that this television is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Deutsch
Hiermit erklärt Philips Innovative Applications N.V. dass sich das Fernsehgerät in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

Français
Par la présente Philips Innovative Applications N.V. déclare que cet appareil de télévision est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Nederlands
Hierbij verklaart Philips Innovative Applications N.V. dat deze televisie in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Español
Por medio de la presente Philips Innovative Applications N.V. declara que el televisor cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Italiano
Con la presente Philips Innovative Applications N.V. dichiara che questo televisore è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Português
Philips Innovative Applications N.V. declara que este televisor está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Ελληνικά
ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Η Philips Innovative Applications N.V. ΔΗΛΩΝΕΙ ΟΤΙ Η ΤΗΛΕΟΡΑΣΗ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Svenska
Härmed intygar Philips Innovative Applications N.V. att denna TV står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Norsk
Philips Innovative Applications N.V. erklærer herved at utstyret TV er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

Dansk
Undertegnede Philips Innovative Applications N.V. erklærer herved, at dette TV overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Suomi
Philips Innovative Applications N.V. vakuuttaa täten että tämaä televisio on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Polski
Firma Philips Innovative Applications N.V. niniejszym oświadcza, że 'Telewizor' jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Magyar
Alulírott, Philips Innovative Applications N.V. nyilatkozom, hogy a televízió megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Česky
Philips Innovative Applications N.V. tímto prohlašuje, že tento televizor je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Slovensky
Philips Innovative Applications N.V. týmto vyhlasuje, že tento televízor spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Slovensko
Philips Innovative Applications N.V. izjavlja, da je ta televizor v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Eesti
Käesolevaga kinnitab Philips Innovative Applications N.V. seadme Teler vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Latviski
Ar šo Philips Innovative Applications N.V. deklarē, ka 'Televizors' atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Lietuvių
Šiuo Philips Innovative Applications N.V. deklaruoja, kad šis 'Televizorius' atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Malti
Hawnhekk, Philips Innovative Applications N.V., jiddikjara li dan 'Television' jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Íslenska
Hér með lýsir Philips Innovative Applications N.V. yfir því að 'Television' er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

A copy of the Declaration of Conformity is available at :
http://www.philips.com/support

CE !

This equipment may be operated in the following European countries …

AT	BE	BG	CH	CY	CZ
DE	DK	EE	ES	FI	FR
GB	GR	HU	IE	IS	IT
LI	LT	LU	LV	MT	NL
NO	PL	PT	RO	SE	SK
SL	TR				

This equipment can be operated in other non-European countries.

Italiano
Sistema TV wireless
Informationi sulle normative applicabili

Per il mercato italiano
• uso privato: Decreto legislativo . 259 1/8/2003 Codice delle comunicazione elettroniche. In particulare, l'articolo 104 specifica i casi in cui occorre richiedere un autorizzazione generale, mentre l'Art. 105 indica i casi in cui l'utilizzo è libero
• regolamentazione della fornitura dell' accesso RLAN del pubblico alle reti e ai servizi pubblici di comunicazione elettronica (es. sistema TV wireless). Decreto ministeriale 28/5/2003 e relative modifiche, e Art. 25 (autorizzazione generale per reti e servizi di comunicazione elettronici) del Codice delle comunicazione elettroniche
• uso privato: Decreto ministriale 12/7/2007

Contents

1 To begin 5
1.1 TV tour 5
1.2 Setting up 11
1.3 Keys on the TV 17
1.4 Register your TV 19
1.5 Help and support 20

2 Use your TV 21
2.1 Remote control 21
2.2 Menus 24
2.3 Watch TV 28
2.4 Watch satellite 32
2.5 Watch a connected device 34
2.6 Ambilight 35
2.7 Net TV 37

3 More on ... 40
3.1 Text 40
3.2 Interactive TV 42
3.3 Multimedia 43
3.4 Locks and timers 45
3.5 Subtitles and languages 46
3.6 Universal access 47

4 Setup 48
4.1 Picture, Sound, Ambilight 48
4.2 Channels 49
4.3 Satellite channels 51
4.4 Network 53
4.5 Devices 54
4.6 Software 56

5 Connections 57
5.1 First connections 57
5.2 About cables 58
5.3 Connect devices 60
5.4 Connect more devices 68
5.5 Network 72
5.6 SD card 73
5.7 Common Interface CAM 74
5.8 3D 75

6 Troubleshooting 76
6.1 Contact information 76
6.2 TV and remote control 77
6.3 TV channels 78
6.4 Picture and sound 79
6.5 Devices 80
6.6 Multimedia 81
6.7 Network 82


7 Specifications 83
7.1 Software 83
7.2 Environmental 84
7.3 Power and reception 85
7.4 Display and sound 86
7.5 Display resolutions 87
7.6 Multimedia 88
7.7 Connectivity 89
7.8 Dimensions and weights 90

Index 91


1 To begin

1.1 TV tour


The remote control



To adjust the volume.




To switch TV channels.




To open or close the **Home menu** .

In the Home menu, you can start or stop a TV activity. Like watching TV or watching a movie from a connected DVD player.



To open or close the **Browse menu** .


In the Browse menu, you can open Text, the Channel list or the TV programme guide.



To open or close the **Options menu** .


In the Options menu, you can select settings related to what is shown on screen.

While you watch a channel, mark it as a favourite or stop the slideshow of your photos shown on screen.




To open or close the **Adjust menu** .

In the Adjust menu, you can quickly adjust some picture and sound settings.




Back .

With Back you go back to the previous TV channel or go one step back in a menu.




Red

With the red key, you select the red option or open digital **Interactive TV services** or some TV demonstration clips.




Green

With the green key, you select the green option or the **Eco settings**.



Yellow

With the yellow key, you select the yellow option or the **Help menu**.



Blue


With the blue key, you select the blue option.

Read more about the remote control in **Help** > **Use your TV** > **Remote control** > **Overview**.

Or go to the **Search** page to look for any topic.


Press ▲ to select the next TV tour.

The TV menus



You can operate the TV with the 4 menus.
Discover and learn their specific uses.


- the **Home** menu
- the **Browse** menu
- the **Options** menu
- the **Adjust** menu



To open or close the **Home menu** .

Open the Home menu as a starting point to operate the TV.


In the Home menu, you can start or stop a TV activity. Like watching TV - **Watch TV** - or watching a movie from a connected DVD player.



To open or close the **Options menu**

Open the Options menu to select a setting related to what is shown on screen.


While you watch a channel, mark it as a favourite but also open the DVD disc menu while watching a DVD movie.



To open or close the **Browse menu** .

With an activity started in the Home menu, open the Browse menu to find the activity content.

While watching TV, you can find a channel in the **Channel list** or open **Text**.




To open or close the **Adjust menu**

Open the Adjust menu to quickly adjust the picture and sound settings.

You can set the Smart picture setting to **Game**, which is ideal for gaming, or change the Surround setting of the TV speakers.

Go to the **Search** page to look for any topic in **Help**.

Connecting devices



To connect a DVD, Blu-ray Disc player or game console, use the **HDMI** connection.


The HDMI connection offers the best picture and sound quality and, if your device has **EasyLink** (HDMI-CEC), the TV can add the device in the Home menu automatically.

When a device is added in the Home menu, you can select it to watch its programme. If the device has no EasyLink or you do not use the HDMI connection, you must add the connected device in the Home menu using **Add your devices**.

Read more about Add your devices in **Help** > **Use your TV** > **Menus** > **Home menu**.

Read more about EasyLink in **Help** > **Setup** > **EasyLink HDMI-CEC**.

In the chapter **Help** > **Connections**, drawings like these help you to connect most common devices.



High Definition TV


This TV can display High Definition programmes, but to enjoy HD TV you need to get programmes in HD first. If you are not watching HD programmes, the picture quality will be that of a normal TV.

Watch **HD TV** programmes from . . .
• a Blu-ray Disc player
• a Digital HD receiver connected with HDMI and with a subscription to HD programmes
• Over-the-air HD broadcasts (DVB-T MPEG4)
• channels offering HD on a DVB-C network
• an HD game console connected with HDMI and playing an HD game

HD video clip
To experience the stunning sharpness and picture quality of HD TV, you can start the High Definition video clip from the Home menu. Press **Home** > **Setup** > **Watch demos** (on the second page of the Setup menu).

Contact your dealer for more information.
Go to www.philips.com/support to find FAQs featuring the list of HD channels or providers in your country.

Network and Net TV



PC network
You can connect the TV to your PC network. Enjoy your pictures, videos and music files from your PC on a big TV screen.


Read more about PC Network in **Help** > **Setup** > **Network**.



Net TV
If you have an Internet connection on your home network, you can connect to Net TV. Net TV offers you online movies, pictures, music, infotainment, games and much more.

Read more about Net TV in **Help** > **Use your TV** > **Net TV**.

Satellite receiver



Next to the DVB-T and DVB-C reception, this TV has a built-in satellite DVB-S receiver. You can connect a satellite dish antenna and receive **digital satellite channels**.


Read more about satellite channels in **Help** > **Setup** > **Satellite channels**.

1.2 Setting up

Wall or stand mounting

The 2-in-1 stand that comes with the TV, can be used as a table-top stand or as a wall mount bracket. Instructions to mount the 2-in-1 stand are also included in the printed Start guide.

Read the instructions on the following pages.




Caution
Wall mounting the TV requires special skills and should only be performed by qualified personnel. The TV wall mounting should meet safety standards according to the TV's weight. Read also the safety precautions before positioning the TV.


Koninklijke Philips Electronics N.V. bears no responsibility for improper mounting or any mounting that results in accident or injury.

Unmount the TV from the stand if necessary.


To wall mount the TV, you need the 2 screws used to fix the TV onto the TV stand and the 2 mounting discs as shown.




Unscrew the bolt in the middle of the bar with the supplied hex key.




Turn the bar as shown.



Reposition the bar on the stand and fix the bolt with the hex key.




Fix the stand to the TV.




The TV is mounted at the correct height if your eyes are level with the centre of the screen when you sit down.

Distance between the 2 fixing points . . .
- 81cm/32" = 260mm
- 94cm/37" = 300mm
- 102cm/40" = 300mm
- 117cm/46" = 340mm




TV	X	Y	Z
81cm/32"	260mm	260mm	200mm
94cm/37"	300mm	300mm	225mm
102cm/40"	333mm	300mm	265mm
116cm/46"	381mm	340mm	270mm


Fix the 2 mounting discs. Use screws with a diameter of max 6mm.




Slide the bottom plate of the stand onto the mounting discs.



To level the TV, pull the bottom of the TV towards you slightly and let it slide on the discs.




Unscrew the bolt and turn the bar in the position shown.



VESA info

Your TV is prepared for a VESA-compliant wall mount bracket (not included).
VESA codes to purchase the bracket:
- 81cm/32" VESA MIS-F 100,100,M6
- 94cm/37" VESA MIS-F 200, 300, M6
- 102cm/40" VESA MIS-F 200, 300, M6
- 46PFL8605 : VESA MIS-F 200, 300, M6
- 46PFL9705 : VESA MIS-F 300, 300, M6
- 132cm/52" VESA MIS-F 400, 400, M6

Use a screw length as shown in the drawing.



Positioning the TV

Carefully read the safety precautions before positioning the TV.

• Position the TV where light does not shine directly on the screen.
• Dim lighting conditions in the room for best Ambilight effect.
• Position the TV up to 25 cm away from the wall for the best Ambilight effect.



Position the TV at the ideal viewing distance. Get more from HD TV picture or any picture without straining your eyes. Find the 'sweet spot', right in front of the TV, for the best possible TV experience and relaxed viewing.

The ideal distance to watch TV from is three times its diagonal screen size. When seated, your eyes should be level with the centre of the screen.

Safety and care

Make sure you have read and understood all instructions before using your TV. The warranty becomes invalid if any damage is caused by failure to follow instructions.

Risk of electric shock or fire!
• Never expose the TV or remote control to rain, water or excessive heat.

• Never place liquid containers, such as vases, near the TV. If liquids are spilt on or into the TV, disconnect the TV from the power outlet immediately. Contact Philips Consumer Care to have the TV checked before use.

• Never place the TV, remote control or batteries near naked flames or other heat sources, including direct sunlight.
• Keep candles and other naked flames away from this product at all times.
• Never insert objects into the ventilation slots or other openings on the TV.

• Ensure power plugs do not come under heavy force. Loose power plugs can cause arcing and are a fire hazard.
• Never place the TV or any objects on the power cord.
• When disconnecting the power cord, always pull the plug, never the cord.

Risk of injury or damage to the TV!
• Two people are required to lift and carry a TV that weighs more than 25 kg.
• If you mount the TV on a stand, only use the supplied stand. Secure the stand to the TV tightly. Place the TV on a flat, level surface that can support the weight of the TV.

• When mounting the TV on a wall, ensure that the wall mount can safely bear the weight of the TV set. Koninklijke Philips Electronics N.V. bears no responsibility for improper wall mounting that results in accident, injury or damage.

Risk of injury to children!
Follow these precautions to prevent the TV from toppling over and causing injury to children:
• Never place the TV on a surface covered by a cloth or other material that can be pulled away.
• Ensure that no part of the TV hangs over the edge of the mounting surface.

• Never place the TV on tall furniture, such as a bookcase, without anchoring both the furniture and TV to the wall or a suitable support.
• Educate children about the dangers of climbing on furniture to reach the TV.

Risk of overheating!
Always leave a space of at least 10 cm around the TV for ventilation. Ensure curtains or other objects never cover the ventilation slots on the TV.

Lightning storms
Disconnect the TV from the power outlet and antenna before lightning storms. During lightning storms, never touch any part of the TV, power cord or antenna cable.

Risk of hearing damage!
Avoid using earphones or headphones at high volumes or for prolonged periods of time.

Low temperatures
If the TV is transported in temperatures below 5°C, unpack the TV and wait until the TV temperature reaches room temperature before connecting the TV to the mains.


• Risk of damage to the TV screen! Never touch, push, rub or strike the screen with any object.
• Unplug the TV before cleaning.
• Clean the TV and frame with a soft damp cloth. Never use substances such as alcohol, chemicals or household cleaners on the TV.
• To avoid deformations and colour fading, wipe off water drops as soon as possible.

• Avoid stationary images as much as possible. Stationary images are images that remain onscreen for extended periods of time. Stationary images include onscreen menus, black bars, time displays, etc. If you must use stationary images, reduce screen contrast and brightness to avoid screen damage.

1.3 Keys on the TV


Power switch

Switch the TV on or off with the power switch at the bottom of the TV. When switched off, the TV does not consume any energy.




If the red indicator light is off, switch on the TV with the power switch.

If the red indicator is on (standby indication), press ⏻ on the remote control to switch on the TV. Alternatively, you can switch on the TV from standby with any key on the TV. It takes a few seconds for the TV to start up.



Volume


Press (Volume) **-** or **+** to adjust the volume. Or use the **+** or **-** keys on the remote control.



Ambilight

Press (Ambilight), to switch Ambilight on or off.


While the TV is on standby, you can switch Ambilight on and create an Ambilight LoungeLight effect in your room. Read more about LoungeLight in **Help** > **Use your TV** > **Use Ambilight** > **LoungeLight**



Home


Press (Home) to open the Home menu on screen. You can navigate the Home menu with the Volume **-** or **+** (left or right) and the Channel **-** or **+** (down or up) keys on the TV. To confirm your choice, press again.

Read more about Home in **Help** > **Use your TV** > **Menus** > **Home**



CH Channel

Press **CH** (Channel) **-** or **+** to switch channels. Or use the ▶I or I◀ keys on the remote control.



1.4 Register your TV

Congratulations on your purchase and welcome to Philips.

Register your TV and enjoy a range of benefits including full support (including downloads), privileged access to information about new products, exclusive offers and discounts, the chance to win prizes and even participate in special surveys about new releases.


Go to **www.philips.com/welcome**

1.5 Help and support

Using Help and Search

Help

You can open Help from the Home menu. In most cases, you can also press the **Yellow** key on your remote control to open or close Help directly. For some activities, like Text, the colour keys have specific functions and cannot open Help.



Before you follow the Help instructions, close Help. Press the **Yellow** key or press ⌂ to close Help. When you press the **Yellow** key again, Help will open on the page where you closed it.

Search

In Help, use **Search** to find a topic you need. Select a topic from the list with the navigation keys and press **OK**. The topic you are looking for might not be present on the first page but a few pages further on. Press ▶ to go to the next page.

Online support

To solve any Philips TV related problem, you can consult our online support. You can select your language and enter your product model number.

Go to **www.philips.com/support**

On the support site you can find your country's telephone number to contact us as well as answers to frequently asked questions (FAQs).
You can download new TV software or the manual to read on your PC. You can email a specific question or, in some countries, chat online with one of our collaborators.

Contact Philips

For support, you can call the Philips Consumer Care hotline in your country. Find the telephone number on the printed documentation that came with the TV.
Or consult our website **www.philips.com/support**


TV model number and serial number

You might be asked to provide the TV product model number and serial number. Find these numbers on the packaging label or on the type label on the back or bottom of the TV.


2 Use your TV

2.1 Remote control


Overview




1 Standby
To switch the TV on or back to standby.
2 Home
To open or close the Home menu.
3 Navigation key
To navigate up, down, left or right.
4 OK key
To activate a selection.




5 Browse
To open or close the Browse menu.
6 Next
To switch to the next channel, page or chapter.
7 Previous
To switch to the previous channel, page or chapter.
8 Options
To open or close the Options menu.



9 Back
To go back to the previous channel. To exit a menu without changing a setting. To go back to the previous Text or Net TV page.
10 Adjust
To open or close the most used settings like picture, sound or Ambilight.
11 Volume
To adjust the volume level.
12 Mute
To mute the sound or to restore it.



13 Red colour key
To open interactive TV or to select a Text page.
14 Green colour key
To open the Eco settings or to select a Text page.
15 Yellow colour key
To open and close Help or to select a Text page.
16 Blue colour key
To select a Text page.



17 Number keys and text keypad
To select a TV channel directly or to enter text.
18 Subtitles
To switch Subtitles on or off.
19 Picture format
To change the Picture format.

To learn how to use the remote control, read **Help** > **To begin** > **TV tour** > **Remote control**.

EasyLink Remote Control


The remote control of the TV can also operate a connected device. The device must have EasyLink (HDMI-CEC) and have it switched on. The device must also be connected with an HDMI cable.

Operate an EasyLink device
To operate such a device with the TV remote control, select the device -or its activity- in the Home menu and press **OK**. The commands of all keys, except the key, is forwarded to the device.

If the key you need is not on the TV remote control, you can show extra keys on screen with Show remote control.

Show remote control keys
To show the device keys on screen, press (Options) and select **Show remote control**. Select the key you need and press **OK**.

To hide the remote control keys of the device, press (Back).



In general, these keys open the following device menus:
1 Home menu
2 Setup menu
3 Disc menu (disc content)
4 Pop-up menu
5 Options menu
6 Programme guide
7 Media selection

Read more about EasyLink in **Help** > **Setup** > **Devices** > **EasyLink HDMI-CEC**.


IR sensor

Always make sure you point the remote control at the remote control infrared sensor on the front of the TV.



Batteries

To replace the batteries of the remote control, slide open the small tray at the bottom of the remote control. Use 2 coin-shaped batteries (Type CR2032 – 3V). Make sure the + side of the batteries (top side) point upwards. The small tray has 2 + indicators.



Remove the batteries if you are not using the remote control for a long time. Dispose of batteries according to the end of use directives. Read **Help** > **To begin** > **Setting up** > **End of use**.

Cleaning


Your remote control is treated with a scratch-resistant coating.

To clean the remote control, use a soft damp cloth. Never use substances such as alcohol, chemicals or household cleaners on the TV or remote control.

2.2 Menus


Home

With the Home menu, you can start watching TV or a movie disc or start any other activity. You can add an activity when you connect a device to the TV.
Press ⌂ to open the Home menu.
To start an activity, select it with the navigation keys and press **OK**.
To close the Home menu, press ⌂ again.



Operate a selected device
The TV remote control can operate a device if the device is connected with HDMI and has EasyLink (HDMI-CEC).

Read more about EasyLink Remote control in **Help** > **Use your TV** > **Remote control** > **EasyLink Remote control**.



Add a device
Devices connected with EasyLink (HDMI-CEC) automatically show their activity in the Home menu. A single device can add several activities. The device must be connected with an HDMI cable.
If your connected device does not show itself in the Home menu, EasyLink on the device may be switched off.

If your connected device does not have EasyLink (HDMI-CEC) or is not connected with an HDMI cable, you need to manually add your device with **Add your devices** in the Home menu.

Add your devices
In the Home menu, select **Add your devices** and press **OK**. Follow the instructions on screen.
The TV asks you to select the device and the connection to which the device is connected.
The device or its activities are now added to the Home menu.

Rename a device
To rename an added device or activity, press ⊟ (Options) and select **Rename**. Use the keypad on the remote control as you do for SMS/text messaging to enter the new name.

Delete a device
To delete a device or activity from the Home menu, select the item and press ⊟ (Options) and then select **Remove this device**. If a device or activity keeps appearing in the Home menu after you deleted it, switch off the EasyLink setting on the device to prevent this automatic pop-up appearing again.

Read more about EasyLink in **Help** > **Setup** > **EasyLink HDMI-CEC**.

Options for a device
To view the available options for a device or activity in the Home menu, select it and press ⊟ (Options). You can Rename or Remove devices and activities, Reorder the sequence of them or Restore activities if you deleted one of several activities of a device.

Reorder
To reorder a device or an activity in the Home menu, select it and press ⊟ (Options).
1 Select **Reorder**.
2 With the navigation keys, reposition the device or activity where you want it. You can only reorder the sequence of the added devices and activities.

3 Press **OK** to confirm the position. All devices and activities shift to the right.
You can highlight another device or activity and reposition it.


To stop Reorder, press ⊟ (Options) and select **Exit reorder**.

Restore activities
To recall a deleted activity from a device with several activities, select the device or one of its activities and press ⊟ (Options). Select **Restore activities** and press **OK**. All deleted activities of this device appear again.

Browse

With the Browse menu, you find the channel you want to watch from the Channel list, a future programme from the onscreen Programme guide or a Text page.

Press 🕮 to open the Browse menu.
Select your choice with the navigation keys and press **OK**.
To close the Browse menu, press 🕮 again.



Find your content

While watching TV, open the Browse menu to open the Channel list, the Programme guide or Text.
When other activities are selected in the Home menu, like Browse PC or Browse USB, use the Browse menu to find a picture, music or video stored on your computer or USB.



Channel list

The Channel list shows the TV channels and radio stations installed on your TV.
While watching TV, press 🕮 to open the Browse menu and select **Channel list**. Navigate to a channel or station and press **OK** to watch or listen to the selected channel or station.
Press ↩ (Back) to leave the channel list without changing the channel.

Channel list options

With the Channel list on screen, you can press ☐ (Options) to select the following options :
- Select list
- Mark as favourite
- Reorder
- Rename
- Hide channel
- Show hidden channels

Select list

Use this option to select which channels are shown in the Channel list. The list you select here determines which channels you look through with ⏭ and ⏮ while watching TV.

Mark as favourite

When a channel is highlighted in the Channel list, you can set it as a favourite channel.
Read **Use your TV** > **Watch TV** > **Favourite channels**.

Reorder


You can reposition channels within the list.
1 Press ☐ (Options) and select **Reorder** to start reordering channels.
2 Highlight a channel and press **OK**.
3 Reposition the channel where you want it with the navigation keys. Alternatively, enter the new position directly with the number keys.

4 Press **OK** to confirm the position. You can insert the channel or swap it.
You can highlight another channel and do the same.

To stop Reorder, press ☐ (Options) and select **Exit reorder**.

Rename

You can rename a channel in the Channel list.
1 In the channel list, highlight the channel you want to rename.
2 Press ☐ (Options) and select **Rename** to start renaming. You can enter text directly with the remote control keypad or open a full keyboard on top of the text entry menu.



Enter text with the remote control keypad

Use the navigation keys to position the cursor in the text. Press ↩ (Back) to delete a character.
Use the remote control keypad as you do for SMS/text messaging to enter a character. Use the **1** key to select a special character. Select **Clear** to delete a character.
Select **Done** to end Rename.

Enter text with the on-screen keyboard

To open the on-screen keyboard on top of the text entry menu, press **OK** when the cursor in the text blinks.

On the keyboard, use the navigation keys to position the highlight on a character and press **OK** to enter it. To delete a character, press ↩ (Back) or highlight ⌫ and press **OK**.

To switch from uppercase to lowercase or to a set of special characters, press ⏭ (Next) or ⏮ (Previous).
To edit a character within a line of text, position the cursor on this character and use the ← and → keys at both ends of the on-screen spacebar.
To close the on-screen keyboard, highlight **Done** and press **OK**.

Hide channel

You can hide a channel in the Channel list. When looking through channels, a hidden channel will be skipped.
1 In the Channel list, highlight the channel you want to hide.
2 Press ☐ (Options) and select **Hide channel**. The channel is hidden as soon as you close the Channel list.


Show hidden channels

You can recall all hidden channels and unhide them again.
1 In the Channel list, press ☐ (Options) and select **Show hidden channels**. The Channel list now shows all channels again.
2 Press ☐ (Options) and select **Unhide all** to unhide the previously hidden channels.
Or, if you want to leave the previously hidden channels hidden, press ☐ (Options) and select **Exit**.

☐ Options

The Options menu gives settings related to what is shown on screen. Depending on what is shown, the Options menu holds different settings.


Press ☐ (Options) at any time to see which options are available.
To close the Options menu, press ☐ again.



▯▯▯ Adjust

With the Adjust menu, you can adjust picture, sound and Ambilight settings quickly.

Press ▯▯▯ to open the Adjust menu.
Select your choice with the navigation keys and press **OK**.
To close the Adjust menu, press ▯▯▯ again.



Benefits

In the Adjust menu you can quickly lower or speed up the Ambilight dynamics, adjust the Picture format or shift the picture up a little to view the subtitles and select a preset setting for picture or for sound according to what you are watching. If a Home Theatre System, connected with EasyLink, is forwarding its sound presets, you can select these too.

In the Adjust menu you can adjust the following:

- Ambilight On or Off
- Ambilight dynamics
- Picture format
- Smart picture (presets)
- Smart sound (presets)
- Speakers
- Surround
- Picture shift

Ambilight
Read more about the Ambilight settings in **Help** > **Use your TV** > **Use Ambilight**.

Picture format
Read more about the Picture format settings in **Help** > **Use your TV** > **Watch TV** > **Picture format**.

Smart picture, Smart sound
You can set the TV to the pre-defined setting that best suits what you're watching.
Read more about Smart settings in **Help** > **Use your TV** > **Watch TV** > **Smart settings**

Speakers
To hear the sound through the TV speakers, close Help, press ▯▮▯ (Adjust), select **Speakers** and select **TV**.
Select **Amplifier** if you want to hear the sound through a connected Home Theatre System or Amplifier.
These settings temporarily override any EasyLink settings.

Surround
To switch the TV automatically to the best surround sound mode (depending on the programme being broadcast), close Help, press ▯▮▯ (Adjust), select **Surround** and select **On**.

Picture shift
You can shift the picture on screen in a vertical or a horizontal direction depending on the TV input. For instance, you can shift the picture up vertically to view subtitles fully.


While watching TV, press ▯▮▯ (Adjust), select **Picture shift** and press **OK**. Shift the picture with the navigation keys. Press **OK** to stop Picture shift.

2.3 Watch TV

Switch channels


To watch TV and switch TV channels, make sure the **Watch TV** activity is selected in the Home menu.

To watch TV, press ⌂, select **Watch TV** and press **OK**.




To switch TV channels, press ▶| or |◀ on the remote control. You can use the number keys if you know the channel number or you can use the Channel list to select a channel.

To switch back to the previous channel, press ↩ (Back).



Channel list
To open the Channel list, while watching TV, press 🕮 to open the Browse menu. Select **Channel list** and press **OK**. Select a channel with the navigation keys and press **OK** to switch to the channel.

To leave the Channel list without changing the channel, press ↩ (Back).



Channel list pages
The channel list can have several pages. To view the next or previous Channel list page, press ▶| or |◀.

You can Reorder and Rename channels or make a channel a favourite. Read more about Channel list in **Help** > **Use your TV** > **Menus** > **Browse** 🕮.

Radio channels
If digital broadcasting is available, digital radio stations are installed during installation. Switch to a radio channel just like you switch to a TV channel. A DVB-C channel installation usually places radio stations from channel number 1001 onwards.

Options for watching TV channels
With digital TV broadcast, you can see what programme is on now or coming up next, switch Subtitles on or off or even view the channel diagnostics.

While watching TV channels, press ⊟ (Options) to select an available option.

What's on
This option shows information on the current and next programme on this channel. Use the navigation keys to scroll through text or to go to the next column.

Status
Depending on the broadcast, the Status page will show relevant information. You can use this information to improve the channel signal or to check if certain services are available.

Video selection
Digital TV channels can offer multi video signals (multifeed broadcasts), different camera viewpoints or angles of the same event or different programmes on one TV channel. The TV shows a message to advise if any such TV channels are available. When available, press ⊟ (Options) and select **Video selection** to select your choice.

Favourite channels

In the Channel list you can mark a channel as a favourite. You can set the Channel list to only show your favourite channels.

To open the **Channel list**, while watching TV, press 🕮 (Browse) on your remote control.



Set up a favourite channel
While watching TV, press 🕮 to open the Browse menu. Select **Channel list** and press **OK**. Navigate to a channel you want to mark as favourite and press ⊟ (Options). Select **Mark as favourite**. In the Channel list, the favourite channel is marked with a ★.
You can unmark a favourite channel with **Unmark favourite**.

Only watch your favourite channels
You can set the Channel list to show only your favourite channels.
With the list on screen, press ⊟ (Options) and select **Select list**.
Select **Favourites** from the list and press **OK**.
With the Favourites list selected, you will only see your favourite channels when you look through the channels.

Programme guide

The Programme guide is an on-screen guide for scheduled TV programmes. You can set a reminder to tell you when a programme is due to start or select programmes by genre.

The Programme guide is provided by the broadcaster or Net TV.



To open the Programme guide, while watching TV, press 🕮 to open the Browse menu. Select **Programme guide** and press **OK**.

To leave the Programme guide without changing a setting, press ⮌ (Back).

First use
The first time you open the Programme guide, the TV scans all TV channels for programme guide information. This can take several minutes. This data is stored in the TV. Read also **Update Programme guide** in the Programme guide options.

Programme guide options
Select a programme with the navigation keys and press ⊟ (Options) to select the following :
• **Set reminder**
To set an on-screen reminder for when a programme is due to start, select **Set reminder** and press **OK**. The programme is marked with ◕. To cancel this reminder, select **Clear reminder** and press **OK**.

• **Change day**
View the previous or next day's programmes.
• **More info**
Shows the programme details and summary.
• **Search by genre**
View all programmes selected by genre.

• **Scheduled reminders**
If a reminder is set, you can view a list of all scheduled reminders.
• **Update Programme guide**
After the first scan, the TV stores the programme guide data. If you update or reinstall channels or reorder the Channel list, you will need to update this data.

To update this data, select **Update Programme guide**. Reminders are cleared and the new data is stored.

Specifics
Dependant of the amount of channels carrying programme guide data, the TV stores guide information for up to eight days.


Broadcaster or Network
To select where the Programme guide information comes from, press ⌂ > **Setup** > **TV settings** > **Preferences** > **Programme guide**.

Select **From the network** or **From the broadcaster**.

From the network
Until you link up with Net TV, programme guide information comes from the broadcaster. Once you are connected with Net TV, the TV switches automatically to the Internet for programme guide information.
From the broadcaster
Guide information comes from the broadcaster/operator.

Smart picture and sound settings

For easy picture or sound adjustment, you can select a preset setting for each.
While watching TV, press ▯▮▯ to open the Adjust menu and select **Smart picture** or **Smart sound**. Make a selection from the list and press **OK**.



Smart picture and Smart sound
Smart settings are a combination of preset settings suited to a specific use like gaming or daylight viewing.
You can adjust a specific setting like Brightness or Contrast, Bass or Treble, of a chosen smart setting. The smart setting will remember the adjustments you made.

Adjust smart settings
To adjust a specific setting of a smart setting, select the smart setting and press **OK**. Then press ⌂ and select **Setup**. Select **TV settings**, navigate to the individual setting and adjust it.

To return to the original smart setting values, undoing the adjustments you made, first set the TV in the smart setting you want to reset. Then press ⌂ > **Setup** > **TV settings**, select **Reset**, press **OK** and confirm.

Read more about adjusting separate settings in **Help** > **Setup** > **Picture, Sound and Ambilight**.

Smart picture list
- **Personal** - Your choices made in Personalise picture and sound
- **Vivid** - Ideal for daylight viewing
- **Natural** - Natural picture settings
- **Cinema** - Ideal for watching movies
- **Game** - Ideal for gaming
- **Energy saving** - Energy-conscious settings


- **Standard** - Factory standard settings
- **Photo** - Ideal for viewing photos
- **Custom** - A smart picture setting free for any setting you wish

Smart sound list
- **Personal** - Your personal choices made in Personalise picture and sound
- **Standard** - Factory standard
- **News** - Ideal for speech
- **Movie** - Ideal for watching movies
- **Game** - Ideal for gaming
- **Drama** - Ideal for TV soaps
- **Sports** - Ideal for sports programmes

Picture format

If black bars appear on the screen, you can adjust the picture format to a format that fills the screen.

While watching TV, press ▯▮▯ to open the Adjust menu and select **Picture format**. Select a format from the list and press **OK**.



Picture formats
The following formats are available according to the picture on screen:

- **Auto fill**
Automatically enlarges the picture to fill the screen. Minimal picture distortion, subtitles remain visible. Not fit for PC input.

• Auto zoom
Automatically zooms the picture in to fill the screen as much as possible without distortion. Black bars may be visible. Not fit for PC input.
• Super zoom
Removes the black bars on the side of 4:3 broadcasts. The picture is adjusted to fit the screen.

• Movie expand
Scales the picture to a 16:9 format.

• Wide screen
Stretches the picture to a 16:9 format.

• Unscaled
Expert mode for HD or PC input. Pixel for pixel display. Black bars may appear with pictures from a PC.

Switch to standby

If the TV is on, press ⏻ on the remote control to switch to standby. The red standby key indicator is on.


Although the TV consumes very little power when in standby, energy does continue to be consumed.

When the TV is not in use for an extended period of time, we recommend you switch the TV off completely with the power switch.

2.4 Watch satellite


Switch channels

To watch satellite channels, press ⌂, select **Watch satellite** and press **OK**.



To switch satellite channels, press ▶| or |◀ on the remote control. You can use the number keys if you know the channel number or you can use the channel list to select a channel.

To switch back to the previous channel, press ↩ (Back).




Channel list for satellite
When a satellite installation is performed, the satellite channels are stored in a specific channel list for satellite.
Read more about using the channel list in **Help** > **Use your TV** > **Watch satellite** > **Channel list**.

Channel list

To open the channel list, while watching satellite broadcast, press 🕮 to open the Browse menu. Select **Channel list** and press **OK**. Select a channel with the navigation keys and press **OK** to switch to the channel.

To leave the Channel list without changing the channel, press ↩ (Back).



Channel list pages
The channel list can have several pages. To view the next or previous Channel list page, press ▶| or |◀.

Options
With the Channel list on screen, press ▭ (Options) to select :
- TV / Radio
- Select list
- Sort
- Mark as favourite
- Rename
- Reorder
- Show hidden channels
- Hide channel
- Channel lock

TV / Radio
Set the list to show TV or Radio channels.

Select list
Select the list of channels from all satellites or from one specific satellite. Or show a list of only your favourite satellite channels.
The list you select here determines which channels you look through with ▶| and |◀ while you are watching TV.

Sort
You can sort the Channel list by **Name**, **Number** or in groups of Free to Air and Scrambled channels – **Free / scrambled**.

Mark as favourite
In the Channel list, navigate to a channel you want to mark as favourite and press ▭ (Options). Select **Mark as favourite**. In the list, the favourite channel is marked with a ★. You can unmark a favourite channel with **Unmark favourite**.

Only watch your favourites
You can set the Channel list to show only your favourite channels.
With the list on screen, press ▭ (Options) and select **Select list**.
Select **Favourites** from the list and press **OK**.
With the Favourites list selected, you will only see your favourite channels when you look through the channels.

Reorder and Rename
You can reposition channels within the list or rename a channel.
Read more about Reorder and Rename in **Help** > **Use your TV** > **Menus** > **Browse**.

Hide channel
You can hide a channel in the Channel list.
Read more about Hide channel in **Help** > **Use your TV** > **Menus** > **Browse**.

Show hidden channels
You can recall all hidden channels and unhide them again.
Read more about Show hidden channels in **Help** > **Use your TV** > **Menus** > **Browse**.

Satellite channel lock
You can lock a satellite channel. To watch a locked channel, you need to enter the 4 digit child lock code to unlock. You can lock as many channels you like.

To lock a channel in the Channel list, press (Options) and select **Channel lock**. Enter your 4 digit child lock code. Select any channel in the list, press again and select **Lock channel**. A locked channel is marked with a . Now, you can select another channel to lock or unlock.
To exit Channel lock, press and select **Exit**.

Change the child lock code
To change this 4 digit code, press and select **Setup** > **Satellite settings** and select **Child lock** > **Change code**.

Read more about Child lock and Parental rating in **Help** > **Use your TV** > **Watch satellite** > **Child lock**.

Favourite channels

You can set up your own favourite satellite channels and create a list with only your favourites to look through.

Mark as favourite
In the Channel list, navigate to a channel you want to mark as favourite and press (Options). Select **Mark as favourite**. In the list, the favourite channel is marked with a ★. You can unmark a favourite channel with **Unmark favourite**.

Only watch your favourites
You can set the Channel list to show only your favourite channels.
With the list on screen, press (Options) and select **Select list**.
Select **Favourites** from the list and press **OK**.
With the Favourites list selected, you will only see your favourite channels when you look through the channels.

Read more about the options in the Channel list for satellite in **Help** > **Use your TV** > **Watch satellite** > **Channel list**.

Child lock

To prevent children from watching a channel or a programme, you can lock channels or block age-rated programmes.

Lock a channel
To lock a channel, use the **Channel lock** option in the Channel list.
Read more about Channel lock in **Help** > **Use your TV** > **Watch satellite** > **Channel list**.

Parental rating
Some digital broadcasters have programmes rated. When the rating is equal or higher than the rating you have set for your child's age, the programme will be blocked.

To watch a blocked programme you must enter the Child lock code.
The satellite parental rating is set for all satellite channels.

Set an age rating
Press and select **Setup** > **Satellite settings** and select **Parental rating**.
To select an age rating, you must first enter your 4 digit child lock code. If no child lock code is set yet, you can set the code now.

When the code is entered, you can select the age rating. When the rating of a programme is equal or higher than the rating you have set for your child's age, the programme will be blocked. The TV will ask for the code to unblock the programme. For some operators, the TV only blocks programmes with a higher rating.

Change code
To change the current code, press and select **Setup** > **Channel settings** and select **Child lock** > **Change code**.
Enter the current code and then enter the new code twice. The new code is set.

Forgotten your code ?
To override the code in case you forget it, enter **8888**.

2.5 Watch a connected device

Select a device

When a connected devices is added to the Home menu, you can easily select it.

To select and watch a connected device or activity, press ⌂ to open the **Home menu** and select the device or its activity and press **OK**. Make sure the device is switched on.

Read more about Add your devices in **Help** > **Use your TV** > **Menus** > **Home menu**.

Use the TV remote control

The TV remote control can operate a device if the device is connected with HDMI and has EasyLink (HDMI-CEC).


Read more about EasyLink Remote control in **Help** > **Use your TV** > **Remote control** > **EasyLink Remote control**.

2.6 Ambilight

Benefits

With Ambilight, you enjoy a more relaxed viewing experience and improved perceived picture quality.


Dim the lighting conditions in the room and position the TV up to 25cm away from the wall for the best Ambilight effect. To prevent poor infrared remote control reception, position your devices out of sight of Ambilight.



Adjust

You can use the Adjust menu to set the most used Ambilight settings.

While watching TV, press ▮▮▮ to open the **Adjust menu**.
To close the Adjust menu, press ▮▮▮ again.



Switch Ambilight on or off
In the Adjust menu, select **Ambilight** and press **OK**. Switch Ambilight **On** or **Off**.

Ambilight dynamic
In the Adjust menu, select **Ambilight dynamic** and press **OK**. Adjust the speed at which Ambilight responds to onscreen images.

Ambilight brightness
In the Adjust menu, select **Ambilight brightness** and press **OK**. Adjust the light output of Ambilight.

Ambilight colour
In the Adjust menu, select **Ambilight colour** and press **OK**. Select **Dynamic**, if Ambilight should respond to onscreen images or select one of the fixed colours. Select **Custom** if you want to set a specific fixed colour.

Read more about Ambilight settings in **Help** > **Use your TV** > **Use Ambilight** > **Setup**.

Setup

As well as the settings in the Adjust menu, Ambilight offers some advanced settings. You can set a fixed colour of your own or a delayed Ambilight switch off after you switched off the TV.

To open the Ambilight menu, press ⌂ and select **Setup** > **TV settings** > **Ambilight**.

Custom colour
To set a Ambilight colour of your own, select **Custom** in the Ambilight **Colour** menu. With Custom selected, you can open the **Custom colour** menu. Select **Palette** to choose your own colour. Ambilight Custom colour is a fixed (non-dynamic) colour setting.

Separation
To set the difference in colour level between the lights on each side of the TV, select **Separation**. Separation **Off** gives a dynamic but uniform Ambilight colour.

TV switch off
To set Ambilight to fade out and switch off a few seconds after you have switched off the TV, select **TV switch off**. Allow Ambilight to fade out and switch off completely before you switch the TV back on again.

Scenea lounge light
To always switch off Ambilight when Scenea is switched on, select **Scenea lounge light** and select **Off**.


Wall colour
The colour of the wall behind your TV can influence the colour effect of Ambilight. To correct this influence, select **Wall colour** and select a colour that matches the wall colour. Ambilight will correct its colours to mix best with the colour of the wall behind the TV.

Lounge light mood
Read more about Lounge light mood in **Help** > **Use your TV** > **Use Ambilight** > **Lounge light mood**.

Lounge light mood

When the TV is on standby, you can switch Ambilight on and create a Lounge light mood in your room.

To switch Ambilight on while the TV is on standby, press ⏻ on the TV.



To change the Lounge light mood colour scheme, press on the TV again.

To switch off Lounge light mood, press and hold on the TV for 3 seconds.

You can also set up the colour scheme in the Setup menu.
With the TV switched on, press and select **Setup**. Select **TV settings** > **Ambilight** > **Lounge light mood**. Select the colour scheme with which Lounge light mood will start up.

2.7 Net TV

What is Net TV ?

Net TV offers Internet services and websites tailored for your TV. You can visit popular sites, look at infotainment, rent a movie from a video store or watch a TV show you missed.

Net TV pages
The most popular websites in your country have tailored their web pages for use on TV. Read the newspaper headlines, watch the latest video hit or check the weather forecast.

Net TV programme guide
Once you are connected to Net TV, the TV programme guide uses the Internet to gather its information.

Video stores
With Net TV you can rent your favourite movie from an online rental video store.

Missed a programme?
If a broadcaster offers this service, you can catch-up with a favourite programme you missed. Watch this programme when it suits you.

Read more about Net TV in the following chapters.

New services
New services are added regularly. Consult the Net TV pages from time to time to discover the newly-added services.


Specifics
• The availability of Net TV services vary per country.
• With Net TV you can also link up to the Internet. You can view any website you like but remember that most Internet websites are not tailored to be viewed on a TV screen and certain plug-ins (e.g. to view pages or videos) are not available on your TV.

• Net TV online services can be added, changed or stopped.
• Net TV shows one page at a time and full screen.
• You cannot download and save files or install plug-ins.

What you need

To enjoy Net TV, you need to connect the TV to a router with a high-speed connection to the Internet.

Read **Help** > **Setup** > **Network**.



Once the connection is made, select **Browse Net TV** in the Home menu to start the Net TV on-screen setup.

Read **Help** > **Use your TV** > **Net TV** > **First use**.



First use

1 Agree to the Terms of Use.
2 Register for Net TV.
3 Switch on Parental control.
Net TV is ready for use.

How to register
To register, you need an email address and a PC connected to the Internet. If you skip the registration at first use, you can register from the Net TV Start page later on.

To start the Net TV registration, enter your email address on screen. To open the on-screen keyboard, press **OK** with the text field highlighted. Enter the characters one by one. Select **Register** and press **OK.**

A message will appear if a registration email has been send to your email address. Open the email on your PC and click the link to the registration form. Complete the form and click the button to submit.

On the TV, select **OK** and press **OK** to open the Net TV Start page.

Switch on Parental control
The first time you open the Net TV Start page, you can switch on Parental control. If you switch on Parental control, you need to enter a personal lock/unlock code. Enter a 4 digit code as your Net TV lock/unlock code.

Use the number keys on the remote control. Enter the same code again to confirm.

Net TV is ready to use.

Registration benefits
When you have registered, your favourite or locked Net TV pages are stored as a back-up. Also, the last 16 web addresses (URLs) you visit are stored. You can share these pages with another Net TV television if you register that TV with the same email address.

When registered, you can restore these selected pages after an accidental reset of Net TV with Clear history.

Parental control benefits
With Parental control switched on ...
• you can lock and unlock services and/or categories of services
• some services that are not suitable for children are locked from the start but can be unlocked

Parental control specifics
• Only services on the Net TV pages can be locked. Advertisements and Internet websites cannot be locked.
• Services are locked per country. Categories are locked for all countries.

Browse Net TV

To open Net TV, close this Help and press ⌂, select **Browse Net TV** and press **OK**. The TV links up to Net TV and opens the Start page.

To exit Net TV, press ⌂ and select another activity.



The ★ Start page

The ★ Start page shows your favourite services and some recommended services. You can browse Net TV from this page.

To return to the ★ Start page, press 🕮 (Browse).

Open a Net TV service

Select a Net TV service with ▲ or ▼, ◄ or ► keys. To open a selected service, press **OK**.
A closing lock animation means that the page you have opened is a secure page.

Navigate a Net TV service

Navigating a Net TV service can differ from using another service. You can mainly use the navigation keys and the OK key to browse the service. Some services indicate how to browse their service.
To go back one page, press ↩ (Back).

All services

To view the available services for your country, select ⋮⋮⋮ **Services** and press **OK**.
On this page, you can view all services or view them by category, e.g. **News** or **Entertainment**. To view the services by category, select a category in the column at the left and press **OK**.

Options

Press ☐ (Options) to select the following:
- Lock service
- Mark favourite
- Disable parental control
- Show remote control
- Reload page
- Zoom page
- Security info
- Clear Net TV memory

Lock service

To lock a Net TV service, select its icon and press ☐ (Options). Select **Lock service** and press **OK**. The service icon is marked with a 🔒.
To open a locked service, you must enter your 4 digit code. Once you have opened a locked service, you can delete the lock.

Mark favourites

To mark a service as a favourite, select the service icon and press ☐ (Options). Select **Mark favourite** and press **OK**.
You can mark up to 12 services as favourites. All of your favourite services are shown in the ★ Start page. In ⋮⋮⋮ Services, favourite services are marked with a star ★.

Only Net TV services can be marked as favourites. Advertisements and Internet websites cannot be marked.

Unmark favourites

To Unmark a favourite, select the icon of a favourite service and press ☐ (Options) and select **Unmark favourite**.

Disable parental control

To switch off Parental control, press ☐ (Options) and select **Disable parental control**. Enter the 4 digit code to disable Parental control.

Show remote control

Keys like Play ►, Rewind ◄◄ and Fast Forward ►► can be called up with **Show remote control**.
Press ☐ (Options) and select **Show remote control**. With these keys on screen, you can operate audio or video players. Select a key and press **OK** to carry out its function. Press ↩ (Back) to hide these on-screen keys.

Reload page

If something went wrong during the loading of a page, you can try and reload it. Press ☐ (Options) and select **Reload page**.

Zoom page

To zoom an Internet page in or out, press ☐ (Options) and select **Zoom page**. Use the slider bar to set the enlargement.
To scroll through an Internet page, use the navigation keys to jump from highlight to highlight.

Security info

To view a page's security information, press ☐ (Options) and select **Security info**.

Clear Net TV memory

⚠ **Warning** - this option resets Net TV completely.
To clear the Net TV memory completely, including your Favourite, the Parental control code, passwords, cookies and history, press ☐ (options) and select **Clear Net TV memory**.

Net TV services for another country

Another country might have other services available.
To switch to the services of another country, select **Country : …** at the bottom right of the page and press **OK**. Select a country and press **OK**.

Koninklijke Philips Electronics N.V. bears no responsibility regarding the content and the quality of the content provided by the content service providers.

Internet websites

With Net TV you can also link up to the Internet. You can view any website you like but remember that most Internet websites are not meant to be viewed on a TV screen and certain plug-ins (e.g. to view pages or videos) are not available on your TV.

Open an Internet site

To go to an Internet page, select 🌐 Internet and press **OK**. Using the on-screen keyboard, you can enter the web address you need. Select a character and press **OK** to enter it in the address line at the top of the page. Once you entered the address, select **Go** and press **OK** to load the Internet website.

Use the ▲ or ▼, ◄ or ► keys to navigate to the available links on an open Internet page, press **OK** to go to the link.

Internet history

Net TV will automatically add every site you visit to the history list. Later, you can select a site icon in the list and press **OK** to open it.
To scroll through the history list, use the navigation keys.

Clear Net TV history

With a site icon selected in the history list, you can clear the whole list. Press ▭ (Options) and select **Clear history**.

Video stores


With this TV, you can rent a video from an online video store.
1 Open a video store.
2 Select a video.
3 Make the online payment.
4 Download the video.
5 Start watching.

What you need

To rent and download a video, you need a high-speed Internet connection to the TV. Read more about connecting to the network in **Help** > **Setup** > **Network**.
You also need an SD memory card to insert in the TV SD card slot.

Formatting an SD card

To format an SD memory card as video memory, insert the SD card in the SD slot. The TV will automatically start formatting the SD card. The TV could reject the SD card if the write speed is insufficient for video transfer. Once formatted, leave the card permanently in the slot.



View a video store

To view a video store, press ⌂, select **Net TV** > **Video stores** and press **OK**. The Video stores page shows the available stores for your country. To view a store, select its icon and press **OK**.




Rent a video

To rent a video, select its icon on the video store page and press **OK**. In most cases you can rent a video for 1 day or for a couple of days or even just 1 hour. The way you select and rent a video varies from store to store.

Payment

The store will ask you to log in or to open a new log in account if you don't already have one. The login might consist of your email address and a personal PIN code. When you are logged in, you can select the payment method, a credit card or a value code in most cases. Consult the video store website for more information on their payment terms.

To enter a number code (PIN), use the numbers on the remote control.
To enter an email address, select the text field on the page and press **OK**. Select a character on the keyboard and press **OK** to enter it.



Download the video

Once the payment is complete, you can download the video on the video memory. During the download, you can carry on watching the normal programme until the TV notifies you that the video is ready to play. If you cancel a download, you can still download the video until the rental period expires.

Start watching

To start watching a downloaded video, press ⌂, select **Net TV** > **Video stores** and press **OK**. With your log in, enter the store were you rented the video and select the video from the list of downloaded videos. Select the video and press **OK** to play.

Online TV

Some digital broadcasters offer an Online TV service. With Online TV you can watch a programme you missed. Link up with the broadcasters Online TV page to see what programmes are available.

What you need

To link up with an Online TV service, you need a high-speed Internet connection to the TV.
Read more about connecting to the network in **Help** > **Setup** > **Network**.

Open Online TV from Net TV

To open an Online TV service from Net TV, press ⌂, select **Browse Net TV** and press **OK**. In the Net TV services, look for the icon of the TV channel that broadcasts the programme you want. Select the service and press **OK**.

Open Online TV on a channel

To open the Online TV service of a TV channel directly, press the **Red** key. If this service is available, the TV will open the page of the broadcaster.

The availability of Online TV services varies by country.


3 More on ...

3.1 Text


Text pages

Open Text
To open Text, while watching TV, press 🕮 (Browse) and select **Text**.

To close Text, press ↩ (Back).



Select a Text page
To select a page …
• Enter the page number with the number keys.
• Press ▶I or I◀
• Press ▲ or ▼.
• Press a colour key to select a colour-coded subject at the bottom of the screen.



Text sub-pages
A Text page number can hold several subpages. The subpage numbers are shown on a bar next to the main page number.

To select a subpage, press ◄ or ►.

T.O.P. Text pages
Some broadcasters offer T.O.P. Text.
To open T.O.P. Text within Text, press ⧉ (Options) and select **T.O.P. overview**.

Search Text
You can select a word and scan Text for all instances where this word reoccurs. This a practical way to look for a specific subject.

Open a Text page and press **OK**. Select a word or number with the navigation keys. Now press **OK** again to jump immediately to the next occurrence of this word or number. Press **OK** again to jump to the subsequent occurrence.
To stop the search, press ▲ until nothing is selected.

Text from a connected device
Some connected devices that receive TV channels can also offer Text.

To open Text from a connected device, press ⌂, select the device and press **OK**. While watching a channel, press ⧉ (Options), select **Show remote control** and select the ☰ key and press **OK**. Press ↩ (Back) to hide the remote control keys.
To close Text, press ↩ (Back).

Digital text (UK only)
Some digital TV broadcasters offer dedicated digital text or interactive services on their digital TV channels. These services include normal Text using the number, colour and navigation keys to select and navigate.

To close Digital text, press ↩ (Back).

Digital text is blocked when subtitles are broadcast and Subtitle On is set in the Subtitle menu. Select **Subtitles Off** to allow Digital text.

Text options

In Text, press ▭ (Options) to select the following:
- Freeze page
- Dual screen
- T.O.P. overview
- Enlarge
- Reveal
- Cycle subpages
- Language

Freeze page
To stop the automatic rotation of subpages, press ▭ (Options) and select **Freeze page**.

Dual screen / Full screen
To show the TV channel and Text alongside each other, press ▭ (Options) and select **Dual screen**. Select **Full screen** to switch back to full screen view.

T.O.P. overview
To open T.O.P. Text, press ▭ (Options) and select **T.O.P. overview**.

Enlarge
To enlarge the Text page for more comfortable reading, press ▭ (Options) and select **Enlarge**. To scroll down the page, press ▼ or ▲.

Reveal
To unhide hidden information on a page, press ▭ (Options) and select **Reveal**.

Cycle subpages
To cycle subpage when these are available, press ▭ (Options) and select **Cycle subpages**.

Language
To switch the group of characters that Text uses to display correctly, press ▭ (Options) and select **Language**.

Text setup

Text language
Some digital TV broadcasters have several Text languages available.

To set your primary and secondary Text language, press ⌂ > **Set up** > **Channel settings** and select **Primary** or **Secondary Text** and select your preferred Text languages.

Text 2.5
If available, Text 2.5 offers more colours and better graphics. Text 2.5 is activated as a standard factory setting.
To switch it off, select ⌂ > **Setup** > **TV settings** > **Preferences** > **Text 2.5**.

3.2 Interactive TV


Benefits

Interactive TV can offer additional infotainment or programmes on a digital TV channel. Interactive TV is dependent on the country or broadcast. Benefits range from enhanced text to online TV and much more.

For some iTV services, you need a high-speed connection to the Internet. Read **Help** > **Setup** > **Network**.

Use iTV


To open iTV, press the **Red** key while watching a digital channel. If interactive TV is available, the Home page of the broadcaster opens. To close iTV, press ↩ (Back) repeatedly until the iTV page closes.



3.3 Multimedia

Browse USB

You can view photos or play your music and videos from a USB memory device.
Insert a USB device in the USB connection on the left-hand side of the TV while the TV is switched on. The TV detects the device and opens a list showing its content. If the list does not appear automatically, press ⌂, select **Browse USB** and press **OK**.



To close Browse USB, press ⌂ and select another activity or disconnect the USB device.

View photos

To view photos, select a photo in the list and press **OK**. If there are more photos in the folder, the TV starts a slideshow of these photos.
To stop, press ☐ (Options) and select **Stop**.

To pause or play the slideshow again, press **OK**.
To view the next photo, press ▶|.
To view the previous photo, press |◀.

Options for photos

Press ☐ (Options) to select the following:
• Show info
• Stop
• Play once / Repeat
• Rotate
• Shuffle on / off
• Slideshow speed
• Slideshow transition
• Set as Scenea

Shuffle on

Plays the files randomly.

Set as Scenea

Sets the current photo as a wallpaper photo for Scenea.

Play videos or music

To play videos or music, select the file in the list and press **OK**. If there are more music or video files in the folder, the TV plays the files one after the other. To stop, press ☐ (Options).

To pause or play, press **OK**.
To play the next file in the folder, press ▶|.
To play to the previous file, press |◀.
To fast forward, press ▶.
To rewind, press ◀.

Options for music and videos

Press ☐ (Options) to select the following:
• Stop
• Play once / Repeat
• Shuffle on / off

Music with photos

You can play music and show photos at the same time. You must start the music first then the photos.
1 Select a folder with music files and press **OK**.
2 Select a folder with photo files and press **OK**.
To stop, press ☐ (Options) and select **Stop**.

Mute screen

If you only listen to music, you can mute the TV screen to save energy.
To mute the screen, press the **Green** key, select **Mute screen** and press **OK**. To switch the screen back on, press any key on the remote control.

See the list of compatible playback formats in **Help** > **Specifications** > **Multimedia**.

Browse PC

You can view photos or play your music and videos from a PC in your home network.

What you need

To browse these PC files, you need to connect the TV to your home network. You also need to set the PC media server software to share the files with the TV.
Read more about connecting to a network in **Help** > **Setup** > **Network**.

Browse PC


To browse your PC files, press ⌂, select **Browse PC** and press **OK**. If the network is not yet installed when you select Browse PC, Network installation starts automatically. Follow the instructions on screen.
To close Browse PC, press ⌂ and select another activity.

To select, view and play your files, read **Help** > **More on …** > **Multimedia** > **Browse USB**.

See the list of compatible playback formats in **Help** > **Specifications** > **Multimedia**.

Scenea

With Scenea, you can set a photo as a painting on your TV screen. Select your favourite photo from your collection.
To open Scenea, press ⌂, select **Scenea** and press **OK**. If you did not yet select a photo of your own, a preset photo is shown.
To close the Scenea photo, press a key on the remote control.



Select a photo for Scenea

1 Select a photo from a connected USB device or from a connected PC. This photo must be in JPEG format.
2 With the photo highlighted in the Browse USB or Browse PC list, press (Options) , select **Set as Scenea** and press **OK**. By agreeing to overwrite the current photo, the new photo is set.

Scenea lounge light

To switch off Ambilight when Scenea is on, press (Adjust). Or press (Ambilight) on the front of the TV.

Energy saving

To switch the TV to the energy conscious setting, press (Adjust), select **Smart picture** and press **OK**. Select **Energy saving**.

Specifics

With Scenea switched on, the TV will automatically switch to standby after 4 hours. You will be warned 1 minute before switch off. This automatic switch to standby prevents unnecessary energy use in case you forget that Scenea is on.

If the Sleep timer is set, the TV will also switch to standby after the set time has elapsed.
Scenea has no sound.

3.4 Locks and timers

Child locks

To prevent children from watching a channel or a programme, you can lock channels or block age-rated programmes.

Parental rating
Some digital broadcasters have programmes rated. When the rating is equal or higher than the rating you have set for your child's age, the programme will be blocked.

To watch a blocked programme you must enter the Child lock code. The parental age rating is set for all channels.

Set an age rating
Press ⌂ and select **Setup** > **Channel settings** and select **Child lock** > **Parental rating**.
To select an age rating, you must first enter your 4 digit child lock code. If no child lock code is set, you can set the code now.

When the code is entered, you can select the age rating. When the rating of a programme is equal or higher than the rating you have set for your child's age, the programme will be blocked. The TV will ask for the code to unblock the programme. For some operators, the TV only blocks programmes with a higher rating.

Lock a channel
To lock a channel, press ⌂ and select **Setup** > **Channel settings** and select **Child lock** > **Channel lock**. In the list of channel numbers, select a channel and press **OK** to lock a channel.

In the list, a locked channel is marked with an **X**. Now, you can select another channel to lock or unlock. The lock is activated as soon as you close the menu.

You cannot lock programmes from connected devices.

Change code
To change the current code, press ⌂ and select **Setup** > **Channel settings** and select **Child lock** > **Change code**.
Enter the current code and then enter the new code twice. The new code is set.

Forgotten your code ?
To override the code if you forget it, enter **8888**.

Sleep timer

With Sleep timer you can switch the TV to standby at a specified time.

To set the sleep timer, press ⌂ > **Setup** > **TV settings** > **Preferences** > **Sleep timer**. With the slider bar you can set the time up to 180 minutes in increments of 5 minutes. If set to 0 minutes, Sleep timer is switched off.

You can always switch off your TV earlier or reset the time during the countdown.

3.5 Subtitles and languages

Subtitles

Programme subtitles are available most of the time. You can set subtitles to be constantly displayed. How to set constant subtitles depends on whether a channel is analogue or digital. For digital channels, a preferred subtitle language can be set.

For analogue channels

To show subtitles of a channel, switch to the channel and press 🕮 (Browse), select **Text** and press **OK**. Enter the number of the page that shows subtitles, usually 888, and press 🕮 (Browse) again to close Text. Subtitles will be shown if available. Each analogue channel must be set up separately.

For digital channels


There is no need to activate subtitles in Text for digital channels. You can set a preferred primary and secondary subtitle language. If these subtitle languages are not available for a channel, you can select another available subtitle language.

To set the primary and secondary subtitle language, press ⌂ and select **Setup** > **Channel settings** and select **Languages** > **Primary** and **Secondary subtitles**.

To select a subtitle language when none of your preferred languages is shown, press ⊟ (Options), select **Subtitle language** and select a language you want temporarily.

Subtitle menu

To open the subtitle menu, press ⊡.



In the Subtitle menu, you can switch subtitles **On** or **Off**. Select **On during mute** to show subtitles only when the sound is muted with 🔇.

Audio languages

Digital TV channels can broadcast audio that transmits several languages for a program. You can set the TV to switch to your preferred language if it is available.

To set your preferred audio language, press ⌂ and select **Setup** > **Channel settings** and select **Languages** > **Primary** and **Secondary audio**. The TV will automatically switch to the languages you set, if the language is being broadcast.

To check if an audio language is available, press ⊟ (Options) and select **Audio language**. You can select another audio language from the list.

Some digital TV channels broadcast special audio and subtitles adapted for people who are hearing or visually impaired. Read **More on …** > **Universal access**.

3.6 Universal access

Switch on

With Universal access switched on, the TV is set for use for hearing and visually impaired people.

Switch on

If you did not switch on Universal access at first use, you can still switch it on in Setup.
To switch on Universal access, press ⌂ > **Setup** > **TV settings** > **Preferences** > **Universal access**. Select **On** and press **OK**.

With Universal access switched on in Setup, the Universal access option is added in the Options menu. With Universal menu in the Options menu, you can set specific settings for hearing and visually impaired people.

Hearing impaired

Some digital TV channels broadcast special audio and subtitles adapted for hearing impaired people. With Hearing impaired switched on, the TV automatically switches to the adapted audio and subtitles, if available.

Switch on

To switch on Hearing impaired, press ☐ (Options), select **Universal access** and press **OK**. Select **Hearing impaired**, select **On** and press **OK**.

To check whether a hearing impaired audio language is available, press ☐ (Options), select **Audio language** and look for an audio language marked with a .

If Universal access does not appear in the Options menu, switch on Universal access in the Setup. Read **Help** > **More on …** > **Universal access** > **Switch on**.

Visually impaired

In some countries, some digital TV channels broadcast special audio adapted for visually impaired people. The adapted audio has extra commentary.

Switch on

To switch on Visually impaired, press ☐ (Options), select **Universal access** and press **OK**. Select **Visually impaired** and select **On** or, if available, select the speakers the adapted audio should be played from. If available, the TV will play the visually impaired audio.

Volume - Visually impaired

If available, you can set the volume of the extra commentary.

To check whether a visually impaired audio language is available, press ☐ (Options), select **Audio language** and look for an audio language marked with a .

If Universal access does not appear in the Options menu, switch on Universal access in the Setup. Read **Help** > **More on …** > **Universal access** > **Switch on**.

Key beep

Key beep gives an audio feedback each time you press a key on the remote control. The volume of the beep is fixed.

Switch on

To switch on Key beep, press ☐ (Options), select **Universal access** and press **OK**. Select **Key beep** and select **On**.

If Universal access does not appear in the Options menu, switch on Universal access in the Setup. Read **Help** > **More on …** > **Universal access** > **Switch on**.

4 Setup

4.1 Picture, Sound, Ambilight

Smart settings

You can adjust each Smart setting with the settings in Picture or Sound in Setup, TV settings. Adjust the brightness for a particular Smart picture or adjust the bass for a Smart sound.

To return to the original smart setting values, undoing the adjustments you made, first set up the TV in the smart setting you want to reset. Then press ⌂ > **Setup** > **TV settings**, select **Reset**, press **OK** and confirm.

Read more about Smart picture and sound settings in **Help** > **Use your TV** > **Watch TV** > **Smart picture and sound settings**.

Picture

In the Picture menu, you can adjust all picture settings individually.

To open the Picture settings, press ⌂ > **Setup** > **TV settings** > **Picture**.

• **Contrast**
Sets the contrast level of the picture.
• **Brightness**
Sets the brightness level of the picture.
• **Colour**
Sets the level of colour saturation.
• **Hue**
If NTSC is broadcast, hue compensates the colour variations.
• **Sharpness**
Sets the level of sharpness of fine detail.
• **Noise reduction**
Filters out and reduces the image noise in the picture.

• **Tint**
Sets the colours to **Normal**, **Warm** (reddish) or **Cool** (bluish).
Select **Custom** to set up your own personal settings in the Custom menu.
• **Custom tint**
Use the slider bar to set the colour temperature of the picture.

• **Perfect Pixel HD**
Controls the advanced settings of the Perfect Pixel HD Engine.
— **Perfect Natural Motion** removes motion judder and reproduces smooth movement, especially in movies.

— **200 Hz Clear LCD** / **100 Hz Clear LCD** gives a superior motion sharpness, better black level, high contrast with a flicker-free, quiet image and a larger viewing angle.
— **Super resolution** enables superior sharpness, especially on lines and contours in the picture.

— **Perfect contrast** sets the level at which the TV automatically enhances the details in the dark, middle and light areas of the picture.

— **Dynamic backlight** sets the level at which power consumption can be reduced by dimming the brightness intensity of the screen. Choose for the best power consumption or for the picture with the best brightness intensity.
— **MPEG artefact reduction** smooths the digital transitions in the picture.
— **Colour enhancement** makes the colours more vivid and improves the resolution of details in bright colours.
• **PC mode**
Sets the TV to the ideal pre-defined computer setting if a computer has been connected.

• **Light sensor**
Adjusts the picture and Ambilight settings automatically to the lighting conditions of the room.
• **Picture format**
Read **Help** > **Use your TV** > **Watch TV** > **Picture format**.

• **Screen edges**
Slightly enlarge the picture to hide distorted edges.
• **Picture shift**
Move the picture up / down or left / right with the cursor keys.

Sound

In the Sound menu, you can adjust all sound settings individually.

To open Sound settings, press ⌂ > **Setup** > **TV settings** > **Sound**.

• **Bass**
Sets the level of low tones in the sound.
• **Treble**
Sets the level of high tones in the sound.
• **Surround**
Sets the surround sound effect from internal speakers.

• **Headphones volume**
Sets the volume for the headphone connection of the TV.
• **Auto volume levelling**
Reduces sudden volume differences like at the beginning of adverts or when switching from one channel to another.
• **Balance**
Sets the balance of the left and right speakers to best fit your listening position.

Ambilight

Read the chapter Ambilight in **Help** > **Use your TV** > **Ambilight**.

Eco settings

Eco settings bundle the TV settings that help the environment.

While watching TV, press the **Green** key to open **Eco settings**.
Active settings are marked with a ✓.
Press again to close.

Energy saving
This Smart picture setting sets the picture, together with Ambilight, in the most ideal energy conscious setting. To switch on, select **Energy saving** in Eco settings and press **OK**.
To switch off Energy saving, select another Smart picture in the ▯▮▯ Adjust menu.

Mute screen
If you only listen to music, you can mute the TV screen to save energy. Select **Mute screen** and press **OK**. To switch the screen back on, press any key on the remote control.

Light sensor
The built-in light sensor automatically adjusts the picture, together with Ambilight, to the lighting conditions of the room. To switch on, select **Light sensor** and press **OK**. To switch off, press **OK** again.

4.2 Channels

Reorder and rename

You can reorder and rename channels in the Channel list.

To reorder or rename a channel, read **Help** > **Use your TV** > **Menus** > **Browse**.

Update channels

On first use, the TV installed all channels in the Channel list. If the TV installed digital channels, the TV can automatically update the Channel list with new channels. You can also start an update of the Channel list yourself. The update is for digital channels only.

Automatic channel update

Once a day, at 6 AM, the TV updates the channels and stores new channels. Empty channels are removed. For new or removed channels, a message is shown at TV start up. The TV must be in Standby to automatically update channels.

To switch off the message at start up, press ⌂ > **Setup** > **Channel settings** and press **OK**. Select **Channel installation** > **Channel update message** and select **Off**.

To switch off the automatic channel update, press ⌂ > **Setup** > **Channel settings** and press **OK**. Select **Channel installation** > **Automatic channel update** and select **Off**.

Start an update

To start an update the channel list for new channels yourself, press ⌂ > **Setup** > **Search for channels** and press **OK**. Select **Update channels** and press **OK**. Press **Start**. The update can take a few minutes. Follow the instructions on screen.

DVB-T or DVB-C

If both DVB-T and DVB-C reception is available in your country and if this TV is ready to receive DVB-T and DVB-C for your country, you will have selected one or the other with the channel installation on first use.

If you want to change the DVB setting to start a new channel installation, press ⌂ > **Setup** > **Channel settings** and press **OK**. Select **Channel installation** > **Antenna or Cable DVB** and press **OK**. Select the DVB setting you want.

DVB-C channel installation

For ease of use, all DVB-C settings are set to automatic. If your DVB-C provider gave you specific DVB-C values, like a symbol rate or a frequency, enter these values when the TV asks for them during installation.

DVB-T + DVB-C

You can set up your TV for DVB-T and DVB-C. Install one system followed by the other. When both installations are complete, the Channel list will show both DVB-T and DVB-C channels.

Reinstall

On first use, the TV installed all channels in the Channel list. You can redo this full installation to reset your language, country and install all available TV channels.

Full installation

To reinstall the TV, press ⌂ > **Setup** > **Search for channels** and press **OK**. Select **Reinstall channels** and press **OK**. Press **Start**. The update can take a few minutes. Follow the instructions on screen.

You can reorder and rename channels in the Channel list.

Reception quality

If you receive digital TV broadcasting (DVB), you can check the quality and signal strength of a channel.
If you use an antenna, you can reposition the antenna to try and improve the reception.

To check the reception quality of a digital channel, switch to the channel and press ⌂ > **Setup** > **Channel settings** and press **OK**. Select **Channel installation** > **Digital : reception test** and press **OK**.

The digital frequency is shown for this channel. If the reception is poor, you can reposition your antenna. To check the signal quality of this frequency again, select **Search** and press **OK**.

To enter a specific digital frequency yourself, select the frequency, position the arrows on a number with ▶ and ◀ and change the number with ▲ and ▼. To check the frequency, select **Search** and press **OK**.

If you use DVB-C to receive channels, the options **Symbol rate mode** and **Symbol rate** are available. For Symbol rate mode, select **Automatic** unless your cable provider gave you a specific symbol rate value. To enter the symbol rate value, use the number keys.

Manual installation — Analogue

Analogue TV channels can be manually tuned in channel by channel.

To install analogue channels manually, press ⌂ > **Setup** > **Channel settings** and press **OK**. Select **Channel installation** > **Analogue : manual installation** and press **OK**.

1 System

To set up the TV system, select **System** and press **OK**. Select your country or part of the world where you are now.

2 Find channel

To find a channel, select **Find channel** and press **OK**. Select **Search** and press **OK**. You can also enter a frequency yourself. If the reception is poor, press **Search** again. If you want to store the channel, select **Done** and press **OK**.

3 Fine tune

To fine tune a channel, select **Fine tune** and press **OK**. You can fine tune the channel with ▲ or ▼. If you want to store the found channel, select **Done** and press **OK**.

4 Store

You can store the channel on the current channel number or as a new channel number. Select **Store current channel** or **Store as new channel**.

You can redo these steps until you find all available analogue TV channels.

Clock settings


In some countries, digital broadcasts do not send UTC - Coordinated Universal Time information. The daylight saving change might be ignored and the TV might show an incorrect time.

To correct the TV clock, press ⌂ > **Setup** > **TV settings** > **Preferences** > **Clock** and select **Country dependent**. Select **Daylight saving** and select the appropriate setting.
To set the time and date manually, select **Manual**. Then select **Time** or **Date**.

4.3 Satellite channels

Introduction

As well as the DVB-T and DVB-C reception, this TV has a built-in satellite **DVB-S receiver**. With a satellite dish antenna connected, you can receive **digital satellite channels**. You do not need an external satellite receiver.



LNB
An LNB -Low Noise Block-downconverter- captures the signals from a satellite and is mounted at the end of the pole on the dish antenna. The TV can receive signals from 4 different LNBs.

Installation

With a properly set-up and connected satellite dish antenna, you can install satellite channels on the TV.
You can install channels from 4 different satellites (4 LNBs).

1 Install
To search for satellites and install satellite channels, press ⌂ > **Setup** > **Search for satellite** and press **OK**. If you have already installed satellites, select **Reinstall channels** and press **OK**.

2 Connection type
Before you select Start, you must set up the connection type. The connection type will determine the number of LNBs (the number of different satellites) you can install. For ease of use, select the correct type for the number of satellites you want to install.

To set up the connection type, select **Settings** and press **OK**. Select **Connection type** and select **One LNB** if you have only one LNB, select **DiSEqC Mini** for 2 LNBs or select **DiSEqC 1.0** to install 3 or 4 LNBs. Select **Done** to close the settings.

3 Search for satellites
To start the installation, select **Start** and press **OK**. The TV searches for all available satellites. This can take several minutes. If no satellites are found, check the antenna connections and the position of the dish antenna.

The signal quality shown is not always representative of the signal quality of all channels on that satellite.
To repeat the search for satellites, select **Restart** and press **OK**. If you are satisfied with the satellites found, you can install all their channels.

4 Install channels
To install all channels for the satellites you found, press **Install**. The installation can take several minutes per satellite.
When the installation is finished, you can find all channels in the satellite Channel list.

More settings
For most satellites, you do not need to change the LNB settings but, if you are searching for a specific satellite on C-band for instance, you need to set the LNB you use for this satellite to **Single**. Or, if you are an expert user, you might need a **Custom** setting for the LNBs you use.

Reset
You might have lost track of the settings you set up.
To reset the satellite installation settings to factory settings, select **Reset** in Settings and press **OK**.

Signal reception test
The automatic channel install might have missed a specific channel or channels from a transponder. You can add a transponder with Signal reception test. Read **Help** > **Setup** > **Satellite channels** > **Signal reception test**.

Dish antenna connection
Read more about the antenna connection for satellite in **Help** > **Connections** > **First connections** > **Satellite antenna**.

Add or Remove

If satellite channels are already installed, you can add an extra satellite to the installation. You can install channels from 4 different satellites - 4 LNBs.

1 Connection type
Check the Connection type setting before you add a satellite. The setting **One LNB** receives only one LNB, the setting **DiSEqC Mini** receives only 2 LNBs and the setting **DiSEqC 1.0** can receive 3 or 4 LNBs.

To check the Connection type first, press ⌂ > **Setup** > **Search for satellite** and press **OK**. Select **Reinstall channels** and select **Settings** and press **OK**. Select **Connection type** and select the setting you need for the number of satellites you want to install. Select **Done** to close the settings. Press ↩ to close Reinstall channels.

2 Add a satellite
To add a satellite, press ⌂ > **Setup** > **Search for satellite** and press **OK**. Select **Add satellite** and press **OK**. The TV searches for a satellite on the first free LNB. This can take several minutes.

If no satellites are found, check the antenna connections and the position of the dish antenna. Select **Restart** or **Next LNB**.
If there are no free LNBs, you can remove a satellite first. Read Remove satellite in **Help** > **Setup** > **Satellite channels** > **Remove channels**.

3 Install channels
If you are satisfied with the added satellite, you can install the channels.
To install all channels, press **Install**. The installation can take several minutes. When the installation is complete, you can find the added channels in the satellite Channel list.

You can remove a satellite from your satellite installation.

To remove a satellite, press ⌂ > **Setup** > **Search for satellite**. Select **Remove satellite** and press **OK**. Select the satellite you want to remove and press **OK**. To confirm, select **Yes** and press **OK**. The satellite and its channels are removed from the installation.

Update channels

If satellite channels are already installed, you can update the channel list with possible new channels from all installed satellites.

To update the satellite channels, press ⌂ > **Setup** > **Search for satellite**. Select **Update channels** and press **OK**. The TV scans the satellites for new channels and adds them to the list. Empty channels are removed from the list. The update can take several minutes per satellite. When the update has finished, the Channel list for satellite is updated.

Signal reception test

With Signal reception test for satellites, you can check the signal strength of a satellite or you can add a new satellite channel.

To start Signal reception test, press ⌂ > **Setup** > **Search for satellite**. Select **Signal reception test** and press **OK**.
1 Select the **LNB**.
2 If you know the frequency of the transponder (which can hold several channels), select **Frequency** and enter it.
3 Select **Search** and press **OK**.

4 If the TV finds a frequency and there is a store button shown, a new transponder has been found.
5 Press **Store** to add the new transponder with its channel or channels to the Channel list.
To add another transponder, select **Exit** and repeat the steps.

Troubleshooting

The TV cannot install the satellite I want
- Check the orientation of the dish antenna.
- Check the setting for the LNB that you use for this satellite.
- Check the Connection type in the satellite installation settings.
- Reset all Satellite settings if you lost track of the settings you changed. Read **Help** > **Setup** > **Satellite channels** > **Installation**.

The reception of a satellite channel is poor
- Check the orientation of the dish antenna.

Sometimes the reception is poor
- Check if the dish antenna is solidly mounted. Strong winds can move the dish.
- Snow and rain can degrade reception.

Read more about troubleshooting in **Help** > **Troubleshooting**.

4.4 Network


Benefits

Browse PC
If you connect the TV to a home network, you can play photos, music and videos from your computer or storage device. Once the network is installed on the TV, you can find and play the files from your PC on the TV screen.

Net TV
If you connect the TV to a home network, you can link up the TV to Net TV. Net TV offers Internet services and websites tailored to your TV. Play music and videos, consult infotainment, rent movies and much more. Once the network is installed, you can enjoy the best of the Internet for your TV.

What you need

To connect the TV to a home network and Internet, you need a router in your home network. The router must be set to DHCP server on. Use a router with a high-speed connection to the Internet.



If you use a wired connection to the router you need a network (Ethernet) cable.

The TV uses a DLNA-certified protocol. You can use a computer with Microsoft Windows XP or Vista, Intel Mac OSX or Linux as the operating system.

Find your PC files
To select your PC files on screen, you need recent media server software on your computer, like Windows Media Player 11 or similar. To find your files on the TV, some media server software must be set up to share the PC files with the TV.

See the list of supported media server software, read **Help** > **Specifications** > **Multimedia**.

Wired installation

Connect the router to the TV and switch on your router before you start the network installation.

To start the wireless network installation, press ⌂, select **Setup** > **Connect to network** and press **OK**. Follow the instructions on screen.

The TV constantly searches for a network connection. The router must be set to DHCP server on.

If asked for, agree to the End User licence Agreement.

Read more about how to connect in **Help** > **Connections** > **Network** > **Wired**.

Network settings

To open the Network settings, press ⌂ > **Setup** > **Network settings** and press **OK**.

You can view the network type, IP and MAC address, the signal strength, speed and encryption method etc. You can set DHCP and Auto IP, the IP configuration settings, DMR and the TV network name.

4.5 Devices

EasyLink HDMI-CEC

With the TV remote control you can operate devices that have EasyLink (HDMI-CEC) and are connected with an HDMI cable. Devices with EasyLink automatically show their activity in the Home menu. The TV comes with EasyLink switched on.

With an EasyLink device connected, EasyLink offers the following:

• **One touch play**
Insert a disc and press Play on the device. The TV switches on from standby and starts playing the disc.

• **System standby**
Press ⏻ on the remote control to switch all EasyLink devices to standby.

Make sure that all HDMI-CEC settings are properly set up on the device. EasyLink and EasyLink Remote control might not work with devices from other brands.

HDMI-CEC on other brands
The HDMI-CEC functionality has different names on different brands. Some examples of name are: Anynet, Aquos Link, Bravia Theatre Sync, Kuro Link, Simplink and Viera Link. Not all brands are fully compatible with EasyLink.

EasyLink Remote control

With EasyLink Remote Control, the TV remote control can operate the device you are watching on TV. The device must have EasyLink (HDMI-CEC) and have it switched on. The device must also be connected with an HDMI cable.

With an EasyLink device connected, select the device (the activity) and the TV remote control will now operate some or all of the functions of the device.

To switch back to TV, select **Watch TV** in the Home menu and press **OK**.

Switch off EasyLink Remote Control
To switch off EasyLink Remote Control, press Home > **Setup** > **TV settings** and select **EasyLink** > **EasyLink Remote Control** and select **Off**.

Read more about EasyLink in **Help** > **Setup** > **Devices** > **EasyLink HDMI-CEC**.

Add a new device

Devices connected with EasyLink (HDMI-CEC) automatically show their activity in the Home menu. A single device can add several activities. The device must be connected with an HDMI cable.
If your connected device does not appear in the Home menu, on the device EasyLink may be switched off.

If your connected device does not have EasyLink (HDMI-CEC) or is not connected with an HDMI cable, you need to manually add your device with **Add your devices** in the Home menu.

Add your devices
In the Home menu, select **Add your devices** and press **OK**. Follow the instructions on screen.
The TV asks you to select the device and the connection to which the device is connected.
The device or its activities are now added to the Home menu.

Rename a device
To rename an added device or activity, press (Options) and select **Rename**. Use the keypad on the remote control as you do for SMS/text messaging to enter the new name.

Delete a device
To delete a device or activity from the Home menu, select the item and press (Options) and then select **Remove this device**.

If the device or activity, keeps appearing in the Home menu after you deleted it, switch off the EasyLink setting on the device to prevent this automatic pop-up appearing again.

Sound

With an audio system connected, EasyLink also offers the following:

• **System audio control**
If you connect an audio system, you can listen to the audio from the TV through the audio system. The TV speakers are muted automatically.

• **Surround mode**
With a recent Philips device selected in the Home menu, you can change the surround sound setting of the device on the TV. To change this setting, press (Adjust), select **Surround mode** and press **OK**. On **Next mode**, press **OK** to toggle through the available modes on the device.

• **Smart sound**
With a recent Philips device selected in the Home menu, you can change the Smart sound setting of the device on the TV. To change this setting, press (Adjust), select **Smart sound** and press **OK**. Select a sound mode from the list.

• **Screen off**
If a recent Philips device that is selected in the Home menu is only sending audio to the TV, the device may suggest switching off the TV screen. To switch off the screen when this message appears, select **Screen off** and press **OK**. To switch the screen back on, press .

• **TV speakers**
The TV speakers mute automatically when an EasyLink audio device is selected in the Home menu. You can also set the TV speakers to always or never play sound or set the TV to always start up the audio device and play sound from the device.

To set the TV speakers, press > **Setup** > **TV settings** > **EasyLink** > **TV speakers**. Select **EasyLink Autostart** only if you always want to play sound from the audio device.

Audio to Video sync

With a Home Theatre System (HTS) connected to the TV, the picture on TV and the sound from the HTS should be synchronized. A mismatch is visible in scenes with people talking. When they finish sentences before their lips stop moving.

HDMI-ARC
Latest Home Theatre Systems with built-in disc players adjust the audio to video sync automatically when they are connected to the HDMI-ARC connections (HDMI - Audio Return Channel).

Audio sync delay
Other Home Theatre Systems might need an audio sync delay to synchronize. On the HTS, increase the delay value until there is a match between picture and sound. A delay value of 180ms may be required. Read the user manual of the HTS.

With a delay value set up on the HTS, you need to switch off **Audio Out delay** on the TV if the HTS has this delay set up for all its output connections. To switch off Audio Out delay, press ⌂ and select **Setup** > **TV settings** > **Preferences** > **Audio Out delay**. Select **Off** and press **OK**.

If you cannot set up a delay on the HTS or its maximum setting is insufficient, you can switch off the Perfect Natural Motion picture processing of the TV. To switch off Perfect Natural Motion, press ⌂ and select **TV settings** > **Picture** > **Perfect Natural Motion**. Select **Off** and press **OK**.

Auto subtitle shift

If you play a DVD or Blu-ray Disc from a recent Philips player, the TV can move the subtitles upwards. Subtitles will then be visible whatever Picture format you select. The TV comes with Auto subtitle shift switched on.

To switch off Auto subtitle shift, press ⌂ > **Setup** > **TV settings** > **EasyLink** > **Auto subtitle shift**. Select **Off**.

Pixel Plus link

Some other devices, DVD or Blu-ray Disc players, might have their own picture quality processing. To avoid bad picture quality caused by interference with the TV processing, the picture processing of these devices should be disabled. The TV comes with Pixel Plus link switched on and disables the picture quality processing of a connected device.

To switch off Pixel Plus link, press ⌂ > **Setup** > **TV settings** > **EasyLink** > **Pixel Plus link**. Select **Off**.

4.6 Software

Current version

To view the current TV software version, press ⌂ > **Setup** > **Software settings** and press **OK**. Select **Current software info** and read **Version: . . .**.

Update from Internet

If the TV is connected to the Internet, you may receive a message from Philips to update the TV software. You need a high-speed Internet connection.

If you receive this message, we recommend you carry out the update. Select **Update**. Follow the instructions on screen.

You can also look for new updates yourself. To look for an update, press ⌂ > **Setup** > **Update software** and press **OK**. Follow the instructions on screen.

When the update is complete, the TV switches itself off and back on again automatically. Wait for the TV to switch itself back on. Do not use the Power switch ⏻ on the TV.

Update with USB

It might be necessary to update the TV software. You need a PC with an high-speed Internet connection and a USB memory device to upload the software on the TV. Use an USB memory device with 256Mb free space. Make sure that write protection is switched off.

1 Start
2 Identify
3 Download
4 Update TV

1 Start the update on TV

To start the software update, press ⌂ > **Setup** > **Update now**.

2 Identify the TV

Insert the USB memory on the side of the TV, select **Start** and press **OK**. An identification file is written on the USB memory.

3 Download the TV software

Insert the USB memory in your PC. On the USB memory, locate the file **update.htm** and double click it. Click on **Send ID**. If new software is available, download the .zip file. After the download, unzip the file and copy the file **autorun.upg** onto the USB memory. Do not place this file in a folder.

4 Update the TV software

Insert the USB memory in the TV again. The update starts automatically. The TV switches itself off for 10 seconds and then back on again. Please wait.

Do not . . .

- use the remote control
- remove the USB memory from the TV

If a power cut occurs during the update, never remove the USB memory from the TV. When the power returns, the update will continue.

At the end of the update, the message **Operation succesful** appears on screen. Remove the USB memory and press ⏻ on the remote control.

Do not . . .

- press ⏻ twice
- use the ⏻ switch on the TV

The TV switches itself off (for 10 seconds) and then back on again. Please wait.

The TV software has been updated. You can use the TV again.

To prevent an accidental update of the TV software, delete the autorun.upg file from the USB memory.


5 Connections

5.1 First connections

Power cable

Insert the power cable in the power socket of the TV.

When disconnecting the power cable, always pull the plug, never the cable.




Although this TV has a very low standby power consumption, switch off the TV with the power switch to save energy if you do not use the TV for a long period of time.
Read more about the power switch in **Help** > **To begin** > **Keys on the TV** > **Power switch**.

Make sure the power cable is securely inserted in the TV. Make sure that the power plug in the wall socket is accessible at all times.


Antenna cable

Locate the antenna connection at the back of the TV. Insert the antenna cable securely in the **Antenna** socket.



Satellite antenna cable

Locate the F-type Satellite antenna connection at the side of the TV. Attach the satellite antenna cable to this connection.



5.2 About cables


Cable quality

Before you connect devices to the TV, check which connectors are available on the device. Connect the device to the TV with the highest quality connection available. Good quality cables ensure a good transfer of picture and sound. Read the other chapters of **About cables**.

The connections diagrams shown in **Help** > **Connections** > **Connect devices** are recommendations. Other solutions are possible.

HDMI

An HDMI connection has the best picture and sound quality. One HDMI cable combines video and audio signals. Use an HDMI cable for High Definition (HD) TV signals. An HDMI cable transfers picture and sound signals in only one direction. Do not use an HDMI cable longer than 5m.



EasyLink HDMI-CEC
If your devices are connected with HDMI and have EasyLink, you can operate them with the TV remote control. Read more about EasyLink in **Help** > **Setup** > **Devices** > **EasyLink HDMI-CEC**.

HDMI-ARC
If you have a Home Theatre System with an HDMI-ARC (Audio Return Channel) connection, you can connect this device with the TV with only a HDMI cable. Use the HDMI1 ARC connection.

You can skip the audio cable that is added normally (the cable that connects the TV Digital audio Out to the device Digital audio In). The return audio connection in this HDMI-ARC connector is built-in. You do not need a special HDMI cable.

You can leave the ARC channel switched on if you use the additional digital audio cable. Still you can switch off HDMI-ARC. To switch off the ARC in the HDMI 1 connection, press ⌂ > **Setup** > **TV settings** > **EasyLink** > **HDMI 1 ARC**, select **Off** and press **OK**.


DVI to HDMI
Use a DVI to HDMI adapter if your device only has a DVI connection. Use one of the HDMI connections and add an Audio L/R cable to **Audio In VGA/HDMI** for sound, on the back of the TV.

Copy protection
A DVI and HDMI cable support HDCP (High-bandwidth Digital Contents Protection). HDCP is a copy protection signal that prevents copying content from a DVD disc or Blu-ray Disc. Also referred to as DRM (Digital Rights Managament).

Y Pb Pr


Use the Component Video YPbPr connection together with an Audio Left and Right connection for sound.

Match the YPbPr connector colours with the cable plugs when you connect. YPbPr can handle High Definition (HD) TV signals.




Scart

A scart cable combines video and audio signals. Scart connectors can handle RGB video signals but cannot handle High Definition (HD) TV signals.



Video


If you have a device with only a Video (CVBS) connection, you need to use a **Video to Scart adapter** (not supplied). You can add the Audio L/R connections. Connect the adapter to a Scart connection of the TV.



VGA

Use a VGA cable (DE15 connector) to connect a computer to the TV. With this connection you can use the TV as a computer monitor. You can add an Audio L/R cable for sound.


To connect a computer with the VGA connection, read **Help** > **Connections** > **Connect more devices** > **TV as PC monitor**.




5.3 Connect devices

SoundBar


Use an HDMI cable to connect the device to the TV.



If you use the HDMI-ARC connections on both TV and device, no other cable is needed. If not, read on.




If you do not use the HDMI-ARC connection, add a digital audio cable (cinch coaxial).




Blu-ray Disc / DVD player

Use an HDMI cable to connect the device to the TV.




Home Theatre System with disc player


Use an HDMI cable to connect the device to the TV.



If you use the HDMI-ARC connections on both TV and device, no other cable is needed. If not, read on.



If you do not use the HDMI-ARC connection, add a digital audio cable (cinch coaxial).




Audio to Video synchronisation (sync)
If the sound does not match with the video on screen, you can set a delay on most DVD Home Theatre Systems to match the sound and video.
Read more about Audio to Video sync in **Help** > **Setup** > **Devices** > **Audio to Video sync**.


Do not connect the audio signal from a DVD player or other device directly to the Home Theatre System. Always route the sound through the TV first.

Recorder

Use 2 antenna cables to connect the antenna to the device and the TV.




Add an HDMI cable to connect the device to the TV.




Digital receiver / Sat.

Use 2 antenna cables to connect the antenna to the device and the TV.




Add an HDMI cable to connect the device to the TV.




Dig. receiver + Disc Recorder


First, use 3 antenna cables to connect the devices to the TV.



Then use an HDMI cable to connect the digital receiver to the TV.




Finally, use an HDMI cable to connect the Disc Recorder to the TV.




Dig. receiver + Disc-R + Home Theatre


First, use 3 antenna cables to connect the devices to the TV.




Then use an HDMI cable to connect the digital receiver to the TV.




Then use an HDMI cable to connect the Disc Recorder to the TV.



Then use an HDMI cable to connect the Home Theatre System to the TV.




If you do not use the HDMI-ARC connection on the TV and the device, add a digital audio cable (cinch coaxial).




Digital HD receiver

First, use 2 antenna cables to connect the device to the TV.



Use an HDMI cable to connect the device to the TV.


HDMI
TV
2
Digital HD receiver
HDMI
HDMI


5.4 Connect more devices

Game


Connect a game console to the side or back of the TV. You can use an HDMI, YPbPr or Scart connection. If your game console only has Video (CVBS) and Audio L/R output, use a **Video Audio L/R to Scart** adapter to connect to the Scart connection.

Picture delay
To prevent picture delay while gaming, close Help and press ▯▮▯ (Adjust) and select **Smart picture** > **Game** and press **OK**. After gaming, do not forget to select the Smart picture you normally use for watching TV.

Use an HDMI cable to connect the device to the side of the TV.



Or use a Scart adapter to connect the device to the TV.




HD Game

Use an HDMI cable or YPbPr and Audio L/R cables to connect a High Definition game console to the TV.

To connect a HD Game console, read **Help** > **Connections** > **Connect more devices** > **Game**.

Photo camera

To view pictures stored on your digital photo camera, you can connect the camera directly to the TV. Use the USB connection on the side of the TV to connect. Switch on the camera after you made the connection.




If the list with the content of the camera does not appear automatically, your camera might need to be set to transfer its content with PTP (Picture Transfer Protocol). Read the user manual of the digital photo camera.

Camcorder


Connect a camcorder to the side or back of the TV. You can use an HDMI, YPbPr or Scart connection. If your camcorder only has Video (CVBS) and Audio L/R output, use a **Video Audio L/R to Scart** adapter to connect to the Scart connection.

See the following pages to connect your camcorder.

Use an HDMI cable to connect the camcorder to the side of the TV.



Or use a Scart adapter to connect the device to the TV.




TV as PC monitor


You can connect the TV to your computer as a PC monitor. Before connecting the PC, set the PC monitor refresh rate to 60 Hz.

See the following pages for how to connect your computer.

Use a VGA cable to connect the PC to the VGA connector and an audio L/R cable to connect the VGA Audio L/R to the back of the TV.



Use a DVI to HDMI adapter to connect the PC to HDMI and an audio L/R cable to connect the Audio L/R to the back of the TV.



Ideal TV setting
Set the TV Picture format to Unscaled for the sharpest picture quality. While watching TV, press , select **Picture format** and select **Unscaled**.

For a list of supported resolutions see **Help** > **Specifications** > **Display resolutions**.

Decoder

Use a scart cable to connect a decoder that decodes analogue antenna channels. Use the **EXT1** or **EXT2** connectors on the back of the TV.


You have to assign the TV channel as a channel to be decoded. Then assign the connection where the decoder is connected.
To assign this TV channel, press > **Setup** > **Channel settings** > **Decoder**. Select **Channel** to set up the channel that you want to decode. Select **Status** to set the connection you use for the decoder.

5.5 Network

Wired

To set up the wired network connection, read **Help** > **Setup** > **Network**

Connect the router to the TV with a network cable. Use a standard FTP or STP ethernet cable.



Wi-Fi Ready

This TV is Wi-Fi Ready. With the Wireless USB adapter PTA01 accessory (not supplied) you can connect the TV to your network wirelessly. Next to the wireless connection, the free Wi-Fi MediaConnect software can bring up -project- your PC screen on the TV. You can project video, music, presentations, etc. playing on your laptop or desktop PC.

What you need

To use Wi-Fi MediaConnect, you need to connect the TV to your home network. You need a wireless router.
Read more about connecting to a network in **Help** > **Setup** > **Network**.

Install Wi-Fi MediaConnect

1 Insert the Wi-Fi MediaConnect CD-ROM in your PC. The CD-ROM disc that came with the TV.
2 Your PC starts your Internet browser and opens the Wi-Fi MediaConnect download page - www.philips.com/wifimediaconnect. On the website, you can check the necessary PC system requirements.

3 Enter the code printed on the CD-ROM envelope.
4 Click the 'Download now' button to download the free Wi-Fi MediaConnect software.
5 Once downloaded, start the file 'Wi-Fi MediaConnect_setup.exe'. Follow the instructions on screen.

TV network name

If you have more then one TV in your home network, you can rename this TV. To rename this TV in the network, press ⌂ > **Setup** > **Network settings** and select **TV network name**.

To enter the name, press **OK** to open the on-screen keyboard or use the remote control keypad.

Wi-Fi MediaConnect Help

To read the Wi-Fi MediaConnect Help, right click the program icon in the notification tray of the PC and select **Help**.

Specifics

You can project high definition (HD) or standard definition (SD) video, depending on the processing power of your PC.

The content protection on most DVD or Blu-ray Disc movies might restrict watching the movie on TV when the disc is playing on a PC.
The TV shows PC media files with a small delay.
Wi-Fi MediaConnect is only available for PC.

PC requirements

Windows XP, Vista, Windows 7 (PC only)

Minimum PC requirements
- Intel Pentium Core 2 Duo 1.8GHz
- 512MB RAM
- 200MB free hard disk space
- Wi-Fi 802.11g
- Internet connection

Recommended PC requirements
- Intel Pentium Core 2 Duo 2.1GHz
- 1GB RAM
- 200MB free hard disk space
- Wi-Fi 802.11n
- Internet connection

5.6 SD card

Memory size

To download rented videos from Net TV, you need to insert an SD memory card in the TV SD card slot. Once formatted, leave the card permanently in the slot.


SD memory size
We recommend an SDHC (High Capacity) Class 2 card with a minimum of 4GB memory. For HD movies, a minumum of 8GB memory.

Read more about renting videos in **Help** > **Use your TV** > **Net TV** > **Video stores**.

Insert the card

Make sure to unlock the SD memory card before you insert it.

To format the SD card, switch on the TV and insert the SD card in the SD card slot. The TV will automatically start formatting. Leave the SD card permanently in the slot.



5.7 Common Interface CAM


CAM

Scrambled digital TV channels can be decoded with a Conditional Access Module (CAM). Digital TV service operators provide the CAM when you subscribe to their services. Contact a digital TV service operator for more information and to see terms & conditions.

Insert a CAM

Switch off the TV before inserting a CAM.
Look on the CAM for the correct method of insertion. Incorrect insertion can damage the CAM and the TV.

Look for the common interface slot on the back of the TV. Gently insert the CAM as far as it will go and leave it in the slot permanently.
It can take a few minutes before the CAM is activated. Removing the CAM will deactivate the service on TV.



Watching a CAM service

If a CAM is inserted and subscription fees have been paid, the TV shows the programme from the digital TV service provider. The applications, their function, the content and the onscreen messages all come from the CAM service.

CAM settings

To set passwords or PIN codes for the CAM service, press ⌂ > **Setup** > **Channel settings** > **Common Interface**. Select the CAM provider and press **OK**.

CI+

This TV can handle the CI+ conditional access.
CI+ allows service providers to offer premium HD digital programmes like movies and sports with a high level of copy protection.

To insert a CI+ CAM, read the chapter **CAM - Conditional Access Module.**

5.8 3D

3D

This TV is prepared for future 3D TV accessories (only for 40PFL8605 and 46PFL8605).

6 Troubleshooting

6.1 Contact information

If the advice and suggestions in Troubleshooting do not help resolve the problem, try switching the TV off and back on again.

Warning

If your TV breaks down, **NEVER** try to repair the TV yourself.

Consumer Care

If the TV problem is not solved you can call the Philips Consumer Care hotline in your country. Look up the TV model and serial number before you call. Find the telephone number on the documentation that came with the TV. Or consult our website **www.philips.com/support**

TV model number and serial number

Find these numbers on the packaging label or on the type label on the back or bottom of the TV.

6.2 TV and remote control

The TV does not switch on

• Switch the TV off and on again with the switch on the bottom of the TV.
• Check the power cable connection.
• Try using the keys on the TV to switch on.

The TV does not switch on from standby

• Check that the batteries of the remote control are not empty or weak. Check their + / - orientation.
• Try using the keys on the TV to switch on.

The TV does not respond to the remote control

• Check that the batteries of the remote control are not empty or weak. Check their + / - orientation.
• Clean the remote control and TV sensor lens.

• During start-up, which can take up to two minutes with connected devices, the TV and some external devices do not immediately respond to commands from the remote control. The device is functioning normally and is not broken.

The TV switches off and the red light blinks

• Switch the TV off and on again with the switch at the bottom of the TV. Check if there is enough space for ventilation. Wait until the TV has cooled down.

If the TV does not restart from standby and the blinking occurs again, call Consumer Care.

You forgot your code to unlock Child lock?

Read **Help** > **More on …** > **Locks and timers** > **Child lock**.

6.3 TV channels

Some TV channels are gone

• Check if the correct list is selected in the Channel list. With the Channel list on screen, press ☐ (Options) and select the list you need with **Select list**.

• A channel could be hidden in the Channel list. Read more about Channel list in **Help** > **Use your TV** > **Menus** > **Browse**.

No digital channel found during installation

• Check if the TV supports DVB-T or DVB-C in your country. Check the 'Digital TV Country Compatibility' sticker on the back of the TV.

6.4 Picture and sound

No picture
• Check if the antenna is connected properly.
• Check if the correct device is selected and connected properly.
• Check the contrast or brightness setting in ⌂ > **Setup** > **TV settings** > **Contrast** or **Brightness**.

The picture is poor
• Bad weather can influence the picture quality.
• Check if the antenna is connected properly.
• Non-earthed audio devices, neon lights, high buildings or mountains can influence the picture quality. Try to improve the picture by changing the position of the antenna or placing devices away from the TV.

• Check that the correct TV system is chosen in the Manual installation menu.
• If only a certain channel is poor, try to fine tune this channel with the Fine tune menu. Read **Help** > **Setup** > **Channels** > **Manual installation - Analogue**.

The picture has poor colour
• Check the colour settings in ⌂ > **Setup** > **TV settings**. Or press ▯▮▯ (Adjust) to select a **Smart picture** setting.

Picture delay when a game console is connected
• To prevent picture delay, press ▯▮▯ (Adjust), select **Smart picture** > **Game**.

The TV does not remember my settings when I switch it back on
• Check whether the TV is set to the **Home** location. Press ▯▮▯ > **Setup** > **TV settings** > **Preferences** > **Location**.

The picture does not fit the screen
• Press ▯▮▯ (Adjust), **Picture format** and select **Auto fill**.

The picture position on screen is not correct
• To correct a shifted picture, press ▯▮▯ (Adjust) and select **Picture shift**. Use the navigation keys to adjust the picture position. Press **OK** to stop Picture shift.

• If distorted screen edges are visible, press ⌂ > **Setup** > **TV settings** > **Picture** > **Screen edges** and use the slider bar to enlarge the picture slightly.

There is a picture but no sound
• Check the volume is not set to 0.
• Check the sound has not been muted with 🔇.
• Check that all cables are connected properly.
• If no sound signal is detected, the TV automatically switches off sound. This is proper operation and is not a malfunction.

The sound is poor
• Try any Smart sound setting, press ▯▮▯ (Adjust), **Smart sound**.
• Check that the sound is set to Stereo.

The sound comes from one speaker only
• Check the Balance setting. Press ⌂ > **Setup** > **TV settings** > **Sound** > **Balance**. Use the slider bar to set the balance.

Sound delay
• If there is an audio to video sync mismatch when sound comes from a Home Theatre System, an audio sync delay needs to be set up. Read more about Audio to Video sync in **Help** > **Setup** > **Devices** > **Audio to Video sync**.

6.5 Devices

HDMI connections

• The HDMI-HDCP procedure might take a few seconds before the picture from a device appears.
• If the TV does not recognise the device and there is no picture, try switching from one device to another and back again to restart the HDCP procedure.

• If sound interruptions occur persistently, see the user manual of the device to check the output settings. If that does not help, connect an additional audio cable.
• If a DVI to HDMI adaptor is used, check that an additional audio connection is in place to complete the DVI connection.

EasyLink HDMI-CEC

• Check if the connected device supports the HDMI-CEC standard and is properly set up. Read the user manual that comes with the device.
• Check if the HDMI cable is properly connected.

• Check if EasyLink on the TV and device is switched on.
• Make sure that the System audio control in your HDMI-CEC audio devices is properly set up. Read the user manual that comes with your audio device.

PC display

• The refresh rate of a PC connected to the TV with VGA or DVI to HDMI adapter should set to 60Hz.
• Check that the correct resolution mode is selected on your PC. See the list in **Help** > **Specifications** > **Display resolutions**.

6.6 Multimedia

The files on my USB device are not shown

• Set your device (camera) to 'Mass Storage Class' compliant.
• The USB device may need specific driver software. Unfortunately, this software cannot be downloaded to your TV.

• Not all audio and picture files are supported. See the list in **Help** > **Specifications** > **Multimedia**.

Files from a USB device do not play back smoothly

• The transfer performance of the USB device limits the transfer rate.

The files on my PC are not shown

• To look for files on your home network with Browse PC, your PC media server software should be set up to share the files with the TV. See the list of compatible Media server software in **Help** > **Specifications** > **Multimedia**.

6.7 Network

Net TV does not work

• If the connection to the router is OK, check the router connection to the Internet.

• You need a high-speed Internet connection for your router.

7 Specifications

7.1 Software

Software version

To view the current TV software version, press ⌂ > **Setup** > **Software settings** and press **OK**. Select **Current software info** and read **Version:**.

Open source software

This television contains open source software. Philips hereby offers to deliver or make available, upon request, for a charge no more than the cost of physically performing source distribution, a complete machine readable copy of the corresponding source code on a medium customarily used for software interchange.

This offer is valid for a period of 3 years after the date of purchase of this product. To obtain the source code, write to . . .

Open Source Team, Philips Electronics
High Tech Campus Bld HTC-44
5600 AE Eindhoven
The Netherlands
E-mail: open.source@philips.com

Read the Open Source Licences in **Help** > **To begin** > **Open Source Licences**.

7.2 Environmental

Eco-label

Philips continuously focuses on lowering the environmental impact of its innovative consumer products. We aim our efforts towards environmental improvements during manufacturing, reduction of harmful substances, energy-efficient use, end-of-life instructions and product recycling.



Thanks to our environmental effort, this TV has been awarded the European Ecolabel —the flower- (www.ecolabel.eu).
You can find detailed information on standby energy consumption, warranty policy, spare parts and recycling of this TV on the Philips website for your country at **www.philips.com**

Energy saving

Light sensor
To save energy, the built-in ambient light sensor lowers the brightness of the TV screen when the surrounding light darkens.
Energy saving
The Energy saving Smart picture setting, combines several TV settings that result in saving energy.

Low standby power
The class-leading and highly advanced power circuitry brings down the power consumption of the TV to an extremely low level, without losing out on the constant Standby functionality.

Power management
The advanced power management of this TV ensures the most efficient use of its energy. You can check how your personal TV settings, the level of brightness in current onscreen pictures, and the surrounding light conditions determine the relative power consumption.

To check the relative power consumption, press ⌂ > **Setup** and press ▶I. Select **Watch demos** > **Active control** and press **OK**. Select a Smart setting to check the corresponding values.

End of use

Disposal of your old product and batteries
Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC.



Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste. Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.

Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste.



Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.

7.3 Power and reception

Power

Product specifications are subject to change without notice. For more specification details of this product see www.philips.com/support.

Power

• Mains power : AC 220-240V +/-10%
• Ambient temperature : 5°C to 35°C
• Standby power consumtion : < 0.15W
• Power saving features : Light sensor, Eco mode, Picture mute (for radio), Auto switch-off timer, Eco settings menu.

Reception

• Aerial input : 75 ohm coaxial (IEC75)
• Satellite aerial input : 75 ohm F-type
• TV system : DVB COFDM 2K/8K
• Video playback : NTSC, SECAM, PAL
• DVB : DVB Terrestrial*, DVB-T MPEG4*, DVB-C MPEG4*, DVB-S MPEG4 HD, MHEG, DVB-S HD+ support (Astra) - (* see selected countries on the TV typeplate)

• DVB video/audio support : ISO/IEC 13818-2, ISO/IEC 13818-3
• QPSK demodulation : DVB-S2 MPEG4 (EN300307)
• Reed-Solomon decoder support : complies to EN 300421
• Tuner bands : Hyperband, S-Channel, UHF, VHF

• Preset for satellites : Astra (19.2°E), Astra (23.5 °E), Astra (28.2 °E), Hotbird (13.0 °E), TürkSat (42.0 °E)
• LNB : 1 to 4 LNBs supported, Band selection 22 kHz, LNB current 300 mA max, Polarity selection 14/18V, Tone burst mode
• Input frequency range : 950 to 2150 MHz
• Input level range : 25 to 65 dBm
• Symbol rate : 2 to 45 Msymbols (SCPC and MCPC)

7.4 Display and sound

Display / Picture

• Diagonal size :
- 32PFL8605 : 81cm / 32"
- 37PFL8605 : 94cm / 37"
- 40PFL8605 : 102cm / 40"
- 46PFL8605 : 116cm / 46"
- 52PFL8605 : 132cm / 52"

• Picture enhancement :
- Perfect Pixel HD Engine
- 32PFL8605 : 100Hz Clear LCD
- 37, 40, 46, 52PFL8605 : 200Hz Clear LCD

• Display type : LCD Full HD, edge LED backlight
• Panel resolution : 1920 x 1080p
• Color processing : 2250 trillion colors 17bit RGB
• Brightness : 500 cd/m2
• Dynamic contrast : 500.000:1
• Response time (typical) : 1 (BEW equiv.) ms

Sound

• Output power (RMS) : 2 x 10W
• Dolby Digital Plus, Dolby Pulse - Dolby and the double-D symbol are registered trademarks of Dolby Laboratories.
• Speaker types : 2 woofers

7.5 Display resolutions

Video formats

Resolution — Refresh rate

- 480i - 60 Hz
- 480p - 60 Hz
- 576i - 50 Hz
- 576p - 50 Hz
- 720p - 50 Hz, 60 Hz
- 1080i - 50 Hz, 60 Hz
- 1080p - 24 Hz, 25 Hz, 30 Hz
- 1080p - 50 Hz, 60 Hz

Computer formats

Resolution — Refresh rate

- 640 x 480p — 60 Hz (VGA/HDMI)
- 600 x 800p — 60 Hz (VGA/HDMI)
- 1024 x 768p — 60 Hz (VGA/HDMI)
- 1280 x 768p — 60 Hz (VGA/HDMI)
- 1360 x 765p — 60 Hz (VGA/HDMI)
- 1360 x 768p — 60 Hz (VGA/HDMI)
- 1280 x 1024p — 60 Hz (HDMI)
- 1920 x 1080i — 60 Hz (HDMI)
- 1920 x 1080p — 60 Hz (HDMI)

7.6 Multimedia

Connections
• USB
• Ethernet LAN RJ-45

Supported USB / memory device formats
• FAT 16, FAT 32, NTFS

Playback formats
• MP3, AAC
• WMA v2 up to v9.2
• Still pictures : JPEG
• MPEG 1, MPEG 2, MPEG 4
• H.264 (MPEG-4 AVC)
• WMV9
• MPEG program and transport stream
• AVI, MP4, MKV, ASF

Supported media server software
• Windows Media Player 11 (for Microsoft Windows XP, Vista or Windows 7)
• Google (for Windows XP)
• Twonky Media — PacketVideo 4.4.9 (for PC and Intel MacOX)(5.0.68 MacOX)
• Sony Vaio Media Server (for Microsoft Windows XP or Vista)
• Sony PS3 media server (for Windows XP)

• Nero 8 — Nero MediaHome (for Microsoft Windows XP)
• DiXiM (for Windows XP)
• Macrovision Network Media Server(for Microsoft Windows XP)
• Fuppes (for Linux)
• uShare (for Linux)
• Philips NAS SPD8020 (v. 1.2.9.47)

• TVersity 1.7 pro (for Windows XP)
• Nokia N82, N96, N95
• Nokia N78, N80, N81, 8GB, N800, N810, N92, N93, N93i,N96
• Samsung SGH-i780

7.7 Connectivity

TV Rear
- EXT1 Scart : Audio L/R, CVBS in, RGB
- EXT2 Scart : Audio L/R, CVBS in, RGB
- EXT3 : Y Pb Pr, Audio L/R
- VGA (D-sub 15), Audio In (stereo mini-jack 3.5mm)
- HDMI 1 - ARC in (HDMI v1.4)
- HDMI 2 in (HDMI v1.3)
- HDMI 3 in (HDMI v1.3)
- Audio In (DVI to HDMI)(stereo mini-jack 3.5mm)

- Audio Out L/R — display synchronised (coaxial-cinch-S/PDIF)
- Headphones (stereo mini-jack 3.5mm)
- Network — (RJ45)
- 3D Out (only for 40PFL8605 and 46PFL8605)

TV Side
- HDMI Side in (HDMI v1.3)
- USB
- Common interface slot (CAM)
- SD card slot (SD High Capacity)(as Video stores memory)

7.8 Dimensions and weights

32PFL8605
Width 779 mm
Height 496 mm
Depth 44 mm
Weight ±13 kg
. . . with TV stand
Height 532 mm
Depth 228 mm
Weight ±16 kg

37PFL8605
Width 900 mm
Height 565 mm
Depth 44 mm
Weight ±16 kg
. . . with TV stand
Height 601 mm
Depth 248 mm
Weight ±19 kg

40PFL8605
Width 965 mm
Height 600 mm
Depth 50 mm
Weight ±18 kg
. . . with TV stand
Height 636 mm
Depth 248 mm
Weight ±20 kg

46PFL8605
Width 1102 mm
Height 675 mm
Depth 51 mm
Weight ±25 kg
. . . with TV stand
Height 711 mm
Depth 268 mm
Weight ±28 kg

UMv 3104 327 0033.3 - 100921

52PFL8605
Width 1245 mm
Height 758 mm
Depth 51 mm
Weight ±30 kg
. . . with TV stand
Height 802 mm
Depth 268 mm
Weight ±33 kg

Index

2
2-in-1 stand 11

A
Add a satellite 51
Add your devices 24
Adjust menu 26
Ambilight 35
Ambilight colour 35
Audio Out delay 55
Auto subtitle shift 55

B
Balance 48
Black bars 30
Browse menu 24

C
CAM 74
Channel list 25
Channel list options 25
Channels 28
CI+ 74
Clear Net TV history 39
Clear Net TV memory 38
Clock 50
Common interface slot 74
Component Video YPbPr 58
Connections 58
Consumer Care 76
Current TV software 56

D
Delete a device 24
Digital audio cable 58
Digital text 40
Dual screen 41
DVB 49
DVI to HDMI adapter 58

E
Eco settings 48

F
Favourite channels 29
Favourite satellite channels 33

H
HD TV 9
HD video clip 9
HDMI connection 58
HDMI-ARC (Audio Return Channel) 58
HDMI-CEC 54
Headphone volume 48
Hidden channels 26
Home menu 24
Home network 53

I
Infrared sensor 22
Interactive TV 42
Internet websites 38

L
Lock code 45

M
Media server software 53, 88
Music with photos 43

N
Net TV 37
Net TV lock 37

O
On during mute 46
On-screen keyboard 26
Online video store 39
Open source software 83
Options menu 26

P
Parental rating 45
Perfect Pixel HD Engine 48
Picture delay 68
Picture settings 48
Picture shift 27
Pixel Plus link 55
Play videos 43
Power consumption 84

R
Radio channels 28
Reception quality 49
Rename a channel 25
Rename a device 24
Reorder a channel 25
Router 53

S
Satellite channel lock 33
Satellite installation 51
Satellite parental rating 33
Screen edges 48
SD card slot 73
SD memory card 39
Search 20
Search for satellites 51
Select list 25
Smart sound 30
Sound settings 48
Subtitle language 46
Surround sound 27

T
T.O.P. Text 41
TV tour 7

U
Universal access 47
Update channels 49
Update satellite channels 52

V
Video (CVBS) connection 59
Video selection 28
View photos 43

W
Wall colour 35
Watch satellite 32
Watch TV 28
Wired network 53
Wired network connection 72

Philips Consumer Lifestyle

Philips Consumer Lifestyle BV. Tussendiep 4 9206 AD Drachten Netherlands.

AGB32-JLA-15.1005
(Report No. / Numéro du Rapport)

CE2010
(Year in which the CE mark is affixed)
(Année au cours de laquelle le marquage CE a été apposé)

EC DECLARATION OF CONFORMITY

(DECLARATION DE CONFORMITE CE)

We / Nous, PHILIPS CONSUMER LIFESTYLE BV.
(Name / Nom de l'entreprise)

TUSSENDIEP 4, 9206 AD DRACHTEN, NETHERLANDS
(address / adresse)

declare under our responsibility that the electrical product:
(Déclarons sous notre propre responsabilité que le produit électrique:)

Philips
(brand name, nom de la marque)

32/40/46PFL9705H/12 H/60 K/02 M/08, 58PFL9955H/12
(Type version or model, référence ou modèle)

LCD Television Receiver with integrated Wi-Fi module WUS-N11
(product description, description du produit)

to which this declaration relates is in conformity with the following standards:
(Auquel cette déclaration se rapporte, est conforme aux normes harmonisées suivantes)

EN60065:2002+A1:2006, A11:2008	EN61000-4-3:2006, -4-4:2004
EN55013:2001+A1:2003, A2:2006	EN300328: V1.7.1
EN55020:2007 EN55022:2006	EN301489-17: V1.8.1+V1.3.2:2008
EN61000-3-2:2006, -3-3:1995+A1:2001	EN62311:2008 EN62087:2003
EN61000-4-2:1995+A1:1998, A2:2001	EN55024:1998+A1:2001, A2:2003

(title, number and date of issue of the standard / titre, numéro et date de parution de la norme)

following the provisions of LVD, EMC, EuP and R&TTE Directives
(Conformément aux exigences essentielles de)
and is produced by a manufacturing organisation on ISO9001 level.
(Et sont fabriqués conformément à une qualité au moins conforme à la norme ISO 9001)



Brugge, 2010-05-06
(place, date / lieu, date)

Jan Laurent, Approbation Mgr.
(signature, name and function / signature, nom et fonction)

Contact information

Argentina	0800 8888 7532 (gratuito)
België / Belgique	0800 80 190 (gratis / gratuit)
Brazil	0800 701 0203
	Sao Paulo (11) 2121 0203
България	+3592 489 99 96
	(Местен разговор)
Česká republika	800 142840 (Bezplatný hovor)
China / 中国	4008 800 008
Danmark	3525 8759 (lokalt opkald)
Deutchland	0800 000 7520 (kostenlos)
Ελλάδα	0 0800 3122 1280
	Κλήση χωρίς χρέωση
España	900 800 655 (gratuito)
Estonia	6008600 (local)
France	0805 025 510 (gratuit)
Hrvatska	01 6403 776 (Lokalni poziv)
Italia	800 088 774 (gratuito)
Ireland	0160 11 161 (free)
Northern Ireland	0800 055 6882
Казакстан	007 727 250 66 17 (lokal)
Latvia	527 37691 (local)
Lithuania	67228896 (local)
Luxembourg / Luxemburg	
	0800 26 550 (kostenlos / gratuit)
Magyarország	06 80018 189 (Ingyenes hívás)
Nederland	0800 023 0076 (gratis)
Norge	2270 8111 (lokalsamtale)
Österreich	0800 180 016 (kostenlos)
Polska	022 3491504 (połączenie lokalne)
Portugal	800 780 903 (grátis)
Românä	0800 894910 (gratis)
Россия	
	- Москва (495) 961-1111 - Местный звонок
	- 8-800-200-0880 - Местный звонок
Suisse / Schweiz / Svizzera	
	0800 002 050 (kostenlos / gratuit / gratuito)
Србија	+381 114 440 841 (Lokalni poziv)
Slovakia	0800 004537 (Bezplatný hovor)
Slovenija	00386 1 280 95 00 (Lokalni klic)
Suomi	09 23113415 (paikallispuhelu)
Sverige	08 5792 9100 (lokalsamtal)
Thailand / ประเทศไทย	66 2 652 8652
Türkiye	0800 261 3302 (Şehiriçi arama)
United Kingdom	0800 331 6015 (toll free)

Non-contractual images / Images non contractuelles / Außervertragliche Bilder
All registered and unregistered trademarks are property of their respective owners.

Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners
2010 © Koninklijke Philips Electronics N.V. All rights reserved

www.philips.com